


' * "' F5 B; 9 '9LD@C898 'J=9K G
..... 5 B8 'D5 FHG' @GH

36" Range Frame Detail

Key	Part number	Designation	Q' ty
1	FS-20228055012	Top Shelf	1
2	FS-20228055013	Front deck	1
3	FS-301110405	Knob	6
4	FS-03900267	Oven thermostat knob	1
5	FS-400040	Oven shelf bracket-Left	1
	FS-400041	Oven shelf bracket-Right	1
6	FS-100103	36" oven door assy	1
7	FS-30222032	Oven door hinge roller assy	2
8	FS-20228055015	Burner plate	1
9	FS-100105	36" back splash	1
10	FS-20228055016	Range back support beam 36"	2
11	FS-20228062002	36" Front Panel	1
12		Mylar for 36" range	1
13	FS-20228055008	36" Crumb drawer	1
14	FS-400050	Oven rack, for 36" 60" range	2
15	FS-4000391	Oven bottom panel for 36" range	1
16	FS-302090048	6" adjustable leg	4
17	FS-20228055017	Leg bolt	16
18	FS-2660002	Caster set, for 24"/36" range, 2w/brake	4

' * "' F5 B; 9 ' ; 5 G' GMGH9 A ' 8 9 H5 =@




36" Range Gas System Detail


Key	Part number	Designation	Q' ty
1	FS-302250151	Grate	6
2	FS-302250034	Burner	6
3	FS-20228055018	Short pilot tube	3
4	FS-302220059	Manual gas valve A18	6
5	FS-302220027	Pilot Valve AP6	3
6	FS-03B00050	Oven temperature control valve	1
7	FS-03600125	Oven safety valve	1
8	FS-302150053	Oven orifice #53 LP	1
	FS-3021500381	Oven orifice #38 NG	1
9	FS-302150041 KIT	Orifice #41 NG	6
	FS-3021500520 KIT	Orifice #53 LP	6
10		Orifice mountfitting	3
11	FS-20228055020	Rear burner gas tube	3
12	FS-20228055019	Long pilot tube	3
13	FS-20228055021	Main gas manifold	1
14	FS-309020069	Regulator, for 4&6 burner range	1
15		Oven temperature probe(REF)	1
16	FS-302250035	Oven burner	1
17		Oven pilot bracket	1
18	FS-20228055022	Adapter fitting	3
19		Oven burner gas tube	1
20		Burner orifice assy	1
21	FS-03900080	Oven thermopile	1

'F5 B; 9 '6 I FB9 F'; 5 G'GMGH9 A

: fcbhVi fbYf' [Ug'gmghYa




F YUf'Vi fbYf' [Ug'gmghYa



? Ym	DUFhibi a VYf	E ffm	8 YgW]dh]cb
F	ØÜËHEGGG€É J	î	Ó' } ^ Á ç ^ Á Æ Ì
G	ØÜËHEGGG € Í €GG	H	Ó ç ç ^ Á ç ç *
H	7o \ k) - k M@ 'uy" - 'o-u	H.....	Ü ^ æ Á ^ } ^ Á æ Á ç à ^
I		H	U ä æ Á [^ } ç ç ç *
í		î	À F Á ç ç ç Á ä æ
		î	Á H Á Ú Á ä æ
î	ØÜËHEGGG €EH	î	Ó' } ^

' * "' F5 B; 9 'CJ9 B'; 5 G'GMGH9 A



? Ym	DUFhbi a VYf	E ffm	8 YgW]dhjcb
F	ØÜÈÈÈÈÈ È È È	F	V^ {] ^ æ } ^ ^ & } d [ç æ ^ A ã ã *
G	ØÜÈÈÈ ÈÈÈ È	F	V^ {] ^ æ } ^ ^ & } d [ç æ ^
H	ØÜÈÈÈÈÈ È È È F	F	Uç^ } Å æ Å ~]] Å ã à ^
I	ØÜÈÈÈÈÈ ÈÈFG	F	Uç^ } Å æ Å ç Å ç æ ^
Í		G	Ó {] ^ • • ã } Å ^ c
İ		G	Ó {] ^ • • ã } Å ^ c
Ī	UÜÖÜÜ /	F	Ó } ^ Å æ Å ã à ^
Ì	! æ * ^ Å ç } Å ã à È à È F	F	Uç^ } Å æ Å ã à ^
J	ØÜÈÈÈÈÈ È È È J	F	Ó } ^ Å ã à Å æ • ^
FÈ		F	Uç^ } Å ã à Å ã Ì H S Û
FF		F	Uç^ } Å ã à Å ã Ì Å Õ
FG	ØÜÈÈÈÈÈÈÈ ÈÈÈ	F	Uç^ } Å ã à Å ã Ì c
FH	ØÜÈÈÈÈÈÈÈ È È È È	F	Ó } ^
FI	ØÜÈÈÈÈÈÈÈ È È È F	F	Q ç æ ^ Å ã ^
FÌ	ØÜÈÈÈÈÈÈÈÈÈ È J	F	T æ Å æ Å æ ã ã ã
FĪ		F	Ü ^ * æ
Fİ		F	Uç^ } Å {] ^ æ } ^ ^ à ^ Ç Ü Ø Ø
FĪ	ØÜÈÈÈÈÈÈÈÈÈ È	F	Uç^ } Å @ { [&] ^