

PRESSURE MAT ALARM WITH CHIME

Thank you for purchasing an Ideal Security product.

The 630V2 Pressure Mat Alarm with Chime includes a weight sensing pad (sensor), alarm unit and mounting screws.

The most common use for the pressure mat is as an entry alarm for your home. It can also be used to alert you of the comings and goings of those in your household, or placed in front of cabinets that contain items that might be harmful to children.

Not suitable for extreme weights such as automobiles. Not for industrial or commercial applications.

FEATURES

- A three-position selectable switch for OFF/ALARM/CHIME modes
- A gentle chime to announce visitors, or a loud alarm to deter intruders
- Low (65dB)/Medium (75dB)/High (105dB) sound options for the alarm and chime
- 9V battery operated (not included)
- 30' (approx. 10 meters) wire from mat to alarm unit
- Operating temperature 14°F to 122°F (-10°C to 50°C)
- Trigger sensitivity 1lb per square inch (PSI)

SET-UP

1. Open the battery cover of the alarm unit and install a 9V battery (not included). (Fig. 1)
2. Place the pressure mat on the ground in your place of choice, such as the front of an entrance, at the top or bottom of stairs, or next to a bed; place a lightweight entry mat over it should you want to keep the pressure mat hidden.
3. Keep the pressure mat dry to prevent false alarms, and do not fold the pressure mat as this may damage the sensor.
4. Mount the alarm unit with two screws (included) at a desired location. Connect the alarm unit and the pressure mat. (Fig. 2 and Fig. 3)
5. Set your desired mode (ALARM/CHIME), then cycle your sound option of choice (Low/Medium/High) by pressing the button on the right side. The alarm unit defaults to the Medium sound option upon startup. (Fig. 4 and Fig. 5)

Fig. 1




Fig. 2




Fig. 3




Fig. 4





Fig. 5



OPERATION

When the mat is stepped on, the alarm unit will either emit 2 chimes if set to the CHIME mode or will sound for approximately 30 seconds if set to the ALARM mode. If the mat is not in use, set it to the OFF mode.

BATTERY LIFE

If the alarm sounds weak or the chime sounds distorted, replace the battery immediately.

The battery life will vary depending on the number of uses per day and the selected sound option. If the alarm is triggered an average of 20 times per day, the battery will last for approximately 12 months (if on the Low sound option), approximately 9 months (if on the Medium sound option), or approximately 6 months (if on the High sound option).

WARRANTY

This unit is warranted to be free of defective materials and workmanship for a period of one year from date of purchase. Please keep your bill of sale. In case of malfunction, this unit will be replaced at no charge by Ideal Security Inc. Warranty begins on date of consumer purchase. Replacement as described above shall be the sole remedy to the consumer and there shall be no liability on the part of Ideal Security Inc. for any special, indirect, incidental or consequential damages, including but not limited to any loss of business or profits whether or not foreseeable. For more information, visit www.idealinc.com/policies

CUSTOMER SERVICE

Thank you for your purchase.

We are dedicated to customer service and will work to resolve any difficulties to ensure customer satisfaction.

If you have any questions about the setup or function of this product, please contact us before returning it.

Tel.: 1-800-361-2236

Email: info@idealinc.com

Support and Contact: www.idealinc.com/help

FAQ and Videos: help.idealinc.com



Scan for additional set-up resources

IDEAL SECURITY INC.
LASALLE, QC • PRESCOTT, ON



www.idealinc.com

630V2 - 2023