

How to Remove Your Hot Tub Cover Using the Lift 'N Glide® Cover Lifter by Hot Spring® Spas




1. Unlock the spa straps.



4. Fold the cover over, lift it and it will engage into place.



2. Reach between the hot tub and cover to break the seal between them.



5. For safety purposes, insert the locking pin to prevent accidental closure.



3. Push the cover back until it stops.



6. When you are finished using the hot tub, remove the pin, disengage the cover, close and lock.

Be sure to contact your local Hot Spring dealer to order your replacement cover when you see signs of wear on your spa cover.