


ENGINEERING BULLETIN

Subject: IdealUSA IAssist Add User Date: 11/8/2021 EB072

IdealUSA's new IAssist Device allows for contractors within the same company to view boilers that other contractors within the company have connected. The following steps are to be followed to add new users to the same group.


1. From the home page, hit the 'Users' button on the left side of the page



Ideal USA - 1240 Forest Parkway, Suite 100 - West Deptford, NJ 08066 Tel: 800-411-9999- Fax: 856 228 3584 - e-mail: info@idealusa.com




2. On the Users page hit the '+ Add User' button on the right hand side of the screen





3. Now fill in the form, you can decide if the new user has admin rights or just normal user rights, then hit save.

Admin – Can add/remove users/Admin Users – Cannot add/remove users/Admin



Now either user can monitor all boilers that are connected by either user in the company.

Please contact technical support at <u>techsupport@idealusa.com</u> or 800-411-9999 x575 with any questions.