


# How to Use

The CoolMaster 1000D - Daikin driver is made for integrators and super easy to use:


1. Drag the command to the item,



in the item program just type in the digits of the in-door unit number, for example:  
101 is for the in-door unit number one.



2. Drag the feedback to the item. If you need to add more feedbacks for more in-door units, please note that the text/letters must be the same, for example: to add a room temperature feedback of the in-door unit number two, just add the feedback '**102RoomTemp**'.



Note:

A Global Cache RS232 unit, e.g. iTach IP2SL, is required to connect with the CoolMaster unit. CoolMaster has "Simulation Mode" to simulate an HVAC system in your office. Just send: '**simul x**' (x is the number of in-door units) to the CoolMaster unit. Then you will see on its front LCD screen it starts working. Then you can start your work.

Enjoy!

Innovated Integration Co., Ltd.