

KETTLER®

OUTDOOR FOOSBALL TABLE Model 7199-200 / 7299-400

Adult Assembly Required

Made in Italy



Picture Similar

Printed on recycled paper.

KETTLER® International Inc. • 1355 London Bridge Road • Virginia Beach, VA 23453 USA
www.kettlerusa.com
info@kettlerusa.com

Please do not return this product to the store.
Contact KETTLER® for parts and service: call toll free 866.804.0440 or send email to parts@kettlerusa.com.



Before Assembly (continued)


General Assembly Instructions

- The equipment must be assembled with care by two adults.
- Separate all the parts including the hardware. Compare quantities with the package contents section and that all items are undamaged. If there are any problems, please contact KETTLER®.
- Before assembling the equipment, study the drawings and photos carefully then assemble in the order shown.
- Please note that there is always a danger of injury when working with tools or doing manual work. Therefore, please be careful during assembly.
- Ensure that your working area is free of possible sources of danger, for example don't leave any tools lying around. Always dispose of packaging material in such a way that it may not cause any danger. There is always a risk of suffocation if children play with plastic bags!
- The fastening items required for each assembly step are shown at the beginning of the step. Use the fastening items exactly as instructed.
- Bolt all the parts together loosely at first, and check that they have been assembled correctly. Then use spanner for final tightening. Then check that all screw connections have been tightened firmly.
- For technical reasons, we reserve the right to carry out preliminary assembly work (e.g. addition of tubing plugs).
- Please keep original packaging, so that it may be used for transport at a later date, if necessary. Goods may only be returned after prior arrangement and in packaging that is safe for transportation (in the original box if possible). It is important to provide a detailed defect description/damage report.


Package Contents




Number Included-1



Number Included-2



Number Included-1



Number Included-8



Number Included-5



Number Included-2



Number Included-2

Assembly

Step 1




2 each required



1 required




1 required




1 required

Leg Assembly




Place legs inside cabinet at an outward angle. Horizontal bar between legs should be toward table end. (A)



Ensure holes in side of cabinet align with holes in leg. Insert two M8 x 40 Carriage Bolts from the outside in towards leg. (B)



Using hammer, lightly tap bolt heads into side (C), ensuring they are flush with cabinet (D).



Assembly

Step 3 Rod Assembly




2 sets required

The foosball table comes with 4 telescopic rods for each team.

The bar scheme is as follows:




- Rod with 1x player color 1 (Goalie)
- Rod with 2x players color 1 (Defense)
- Rod with 3x players color 2 (Forwards)
- Rod with 5x players color 1 (Mid-Fielders)
- Rod with 5x players color 2 (Mid-Fielders)
- Rod with 3x players color 1 (Forwards)
- Rod with 2x players color 2 (Defense)
- Rod with 1x player color 2 (Goalie)

Take special care to ensure the direction that the player faces during this assembly step.




REPEAT STEP 3 A-C FOR EACH ROD AS SHOWN BELOW

Use the diagram on Page 6 for additional assistance.



SKIP BALL DROP HOLE



Assembly

Step 4

Rod Bushing Assembly (Continued)



Using 2 of the M4 x 25 screws, fasten the bushing into place.




REPEAT STEP 4 A-G FOR EACH ROD

Assembly

Step 6 Rod Handle Assembly



8 required



Place the rod handle onto the end of the telescopic rod. (A)

Lightly tap handle using a hammer until the handle end reaches the line on the rod closest to the table. (B)



REPEAT THE STEP 6 A-B FOR EACH ROD

Assembly


Step 8 Shroud Assembly




6 required
M4 x 25





1 required




Place the shroud over the table's edge with the rounded edge pointed away from the table as shown. (A)



Using the three M4 x 25 screws, fasten the front of shroud to table. (B)



Using three M4 x 25 screws, fasten the back of shroud to table.




**REPEAT STEP 8 A-C FOR SHROUD ON
OTHER SIDE OF TABLE**


FOOSBALL TABLE COVER



The foosball table comes with a cover included when purchased. Always cover your foosball table when not using. This protects the table from the elements and increases the life of the product to provide many years of enjoyment!



The cover is equipped with a Velcro side opening for ease of use and a tie down to ensure that the cover stays in place.




Log onto www.kettlerusa.com/warranty and register your **KETTLER®** Cavalier Foosball Table Warranty online!



www.facebook.com/kettlerusa



www.youtube.com/kettlerusa



twitter.com/kettler_usa

