




Sport Kid Racer
Assembly Instructions
Model # 9981-590




KETTLER® International, Inc.
1355 London Bridge Road · Virginia Beach, VA 23453 · USA
Parts/Service: 866.804.0440
www.kettlerusa.com
parts@kettlerusa.com

Assembly Instructions

Read these instructions carefully before assembling the product or using it for the first time. They contain important information for your safety and for the correct use and maintenance of this product. Keep the instructions in a safe place for information or for ordering spare parts.

 **WARNING** –*TO AVOID SERIOUS INJURY* Adult supervision required. Never use near steps, slopes, driveways, hills, roadways, alleys, or swimming pool areas. Always wear shoes. Never use near motor vehicles. Never allow more than one rider. The use of protective gear and safety helmet is highly recommended. Riders should always wear a properly fitted helmet that complies with Consumer Product Safety Commission (CPSC) Standard 16 CFR 1203. Adult assembly required.

 **Caution!** Adult Assembly Required. This package contains small parts. Keep away from children until assembled.

This product has been designed in accordance with the latest standards of safety and subjected to constant quality monitoring. The data gained from this quality process is then incorporated in the development of our products. For this reason, we reserve the right to make changes in design and technology in order to offer our customers products of the highest standard of quality at all times.

For your safety

- This pedal car should be used for its intended purpose only, i.e. one (1) child only. It should not be used in any other way, as this may be dangerous. The manufacturer cannot be held liable for damage or injury caused by incorrect use.
- This product is a toy and is not suitable for use in traffic or on public roads.
- Always keep a watchful eye on your child in order to avoid risks by thoughtless and hasty movements.
- This product is suitable for children between 5-9 years and less than 150 lbs. Excessive weight may cause a hazardous or unstable condition.
- The wheeled toy does not contain lights. Please ride during daylight, never in the dark.
- This toy is designed for private use only (no commercial or public use).
- The toy must not be connected with other vehicles, sports or similar devices and not be driven/pulled by them.
- Damaged components may endanger the safety of your child or shorten the lifespan of the product. Inspect it at regular intervals to ensure that none of the components are damaged and that none of the bolts or other joints have worked loose.
- Replace worn or damaged parts immediately and ensure that the product is not used again until this has been done. If any parts require replacement, use only original spares manufactured by KETTLER®.

Assembly Instructions

- This child's wheeled toy conforms to the stipulated safety regulations. Incorrect repairs or alterations (removal of original parts or addition of other parts etc...) may be a source of danger to the user.

Use of the Toy

- Before use, always check all screws and plug-in connections as well as respective safety devices fit correctly.
- Do not transport anything on this product.
- This wheeled toy does not have a parking brake system. Therefore, secure the vehicle against rolling away. Never park the pedal car unattended with a child on it!
- Instruct your child how to use the vehicle correctly and draw attention to possible sources of danger.
- Children at play should always be supervised.
- The seat of this product can be adjusted to your child's size.
- Please bear in mind that there is always a danger of children injuring themselves while using swings, climbing frames, toy vehicles or similar equipment.
- When riding the toy, the child should always wear covered footwear (no open toe shoes or barefoot riding).
- When children are at play, situations may arise which cannot be predicted by the manufacturer and for which the manufacturer cannot be held responsible.
- Never use corrosive or abrasive substances to clean the toy. Never use substances which may cause pollution of the environment.
- For models with air tires, check air pressure periodically (see tire for recommended psi). Due to the nature of materials used in air tires, it is not recommended for the product to be left in any one place for too long where solvents or other chemicals, i.e. petrol, may lie. This may result in a chemical reaction, which could cause the tires to mark the surface such as a vinyl flooring. If in doubt put something underneath the wheels to cover the floor.
- Lubricate the bearing sleeves of the wheels with a few drops of oil every two or three months.

Assembly of the toy vehicle

- Please ensure that the vehicle will only be used for playing when assembly has been carried out correctly, and checked, by an adult.
- The toy vehicle must be assembled carefully by an adult person. Study the assembly instructions carefully before beginning work. Assemble the vehicle in the exact sequence shown by the letters in the diagrams. The vehicle will function as designed when correctly assembled.
- Please note that there is always a danger of injury when working with tools or doing manual work. Therefore please be careful when assembling this product.
- Ensure that your working area is free of possible sources of danger, for example don't leave any tools lying around. Always dispose packaging material in such a way that it may not cause any danger. There is always a risk of suffocation if children play with plastic bags!
- Bolt all the parts together loosely at first, and check that they have been assembled correctly. Tighten the locknuts by hand until resistance is felt, then use wrench to finally tighten nuts completely against resistance (locking device). Then check that all screw connections have been tightened firmly. Attention: once locknuts have been unscrewed they no longer function correctly (the locking device is destroyed), and must be replaced.

Assembly Instructions

- Please keep original packaging of this article, so that it may be used for transport at a later date, if necessary.
- For technical reasons, we reserve the right to carry out preliminary assembly work (e.g. addition of tubing plugs).

List of spare parts page 18-19

When ordering spare parts, always state the full model number, position number, the quantity required.

Example order: Model # 9981-590/position no. 1 / 1 piece

Important: spare part prices do not include fastening material; if fastening material (bolts, nuts, washers etc.) is required, this should be clearly stated on the order by adding the words “**with fastening material**”.

Limited Warranty


THERE ARE NO WARRANTIES, EXPRESSED OR IMPLIED, MADE BY EITHER THE DISTRIBUTOR OR THE MANUFACTURER ON KETTLER® PRODUCTS, EXCEPT THE MANUFACTURER’S LIMITED WARRANTY AGAINST DEFECTS IN MATERIAL SET OUT BELOW:

This KETTLER® Limited Warranty applies to products sold through the KETTLER® Authorized Dealer Network to the original retail purchaser and authenticated by proof of purchase from a retailer located in the United States. Any shipments made under this warranty will be shipped to the United States only. Any shipment outside of the United States will be at the sole cost of the customer. This KETTLER® Limited Warranty is a manufacturer’s warranty and is not changed or modified by additional warranties extended by individual retailers at the point of sale. Manufacturer warrants this product to be free from defects in material at the time of the product’s tender of delivery for a period of 3 year for residential use. This Limited Warranty is not transferable and does not cover normal wear and tear (including, but not limited to, damage and wear to tires, power shocks, drive belts and other non-durable parts). The liability of the manufacturer under this Limited Warranty shall not include any liability for direct, indirect, or consequential damages resulting from the defect. This Limited Warranty is void if the product is damaged by accident, unreasonable use, improper service, failure to follow instructions provided, modification from its original state, or other causes determined not arising out of defects in material.











This warranty gives you specific legal rights. Should this product become defective due to material within the warranty period, contact KETTLER® Parts & Service Dept. by phone at 866.804.0440, fax at 757.563.9273, or e-mail at parts@kettlerusa.com.
















THIS LIMITED WARRANTY IS EXPRESSLY IN LIEU OF ANY OTHER WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, AND OF ANY OTHER OBLIGATIONS OR LIABILITY ON THE PART OF THE MANUFACTURER. KETTLER® NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON TO ASSUME FOR IT ANY OTHER LIABILITY IN CONNECTION WITH SUCH PRODUCTS.

Measuring help for screw connections





Checklist


	1	✓
	1	
	1	
	1	
	2	
	2	
	1	
	1	
	1	
	1	

	1/1	
	1	
	1	
	1	
	2	
 M 8	1	
 Ø 8/20	1	
 Ø 8/16	1	
	12	
 M 5	12	
 M 5 X 53	2	
 M 5 X 45	6	
 M 5 X 30	4	
 M 5 X 27	2	
 3,9 X 16mm	2	


1



2




3




A  M5x30 x 2

B  M5x27 x 2


4




5




6




7




8




9




10



11





Seat Adjustment




Detaching for Repairs and Chain Tightening

Remove seat
Unscrew upper chain cover in location B
Remove upper cover



Unscrew lower cover in location A and remove

Chain Tightening and Re-Attachment




Loosen 4 screws and nuts at location A

Slide pedal sprocket forward (B)
and tighten screws (A) simultaneously to tighten chain

If chain is off, slide pedal sprocket back (C) and place chain on sprockets,
then tighten chain.

Spare parts drawing Sport Kid Racer Pedal Car# 9981-590



Spare parts list Sport Kid Racer # 9981-590

Pos.	Description	Qty.
1	Main Frame	1
2	Tie Rod	1
3	Tie Rod Pin	2
4	Running Wheel	3
5	Spacer Sleeve	2
6	Drive Wheel	1
8	Frame Guard	2
9	Wheel Screen	4
10	Seat	1
11	Steering Wheel Rod	1
12	Steering Wheel	1
13	Steering Wheel Bolt Set	1
14	Steering Column Frame	1
15	Steering Wheel Cap	1
16	Steering Column Casing	1
17	Grill	1
18	Upper Chain Guard Cover	1
19	Lower Chain Guard Cover	1
20	Pedal	2
21	Crank Bearing	2
22	Clamp,Pedal Crank Bearing	2
23	Clutch Lever	1
24	Clutch Grip	1
25	Plug	2
26	Axle	1
27	Chain	1
28	Axle Bearing	2
29	Clamp,Axle Bearing	2
30	Brake Lever	1
31	Brake Grip	1
32	Clamp,Brake Lever	2
33	Pedal Crank	1
34	Adjustment Mechanism	2
35	Tie Rod Cover,Right	1
36	Tie Rod Cover,Left	1
37	Hubcap	4
38	Front Frame	1
39	Rear Frame	1
40	Hardware Bag (not shown)	1

PLEASE DO NOT RETURN
TO THE STORE OR ONLINE
RETAILER

Thank you for purchasing a Kiddi-o® ride-on toy.
If you need help with assembly or have a parts request,
please contact the KETTLER® Parts and Service Department:

- By toll free number 866.804.0440, Monday - Friday, 9 AM to 4:30 PM EST.
- By email: parts@kettlerusa.com
- Additional manuals can be downloaded from our website:
<http://access.kettlerusa.com/retail/homePage/manuals?division=toys&mode=>

Information needed for our parts and service department to efficiently assist you
includes the users manual, model number, date and place of purchase.