

KETTLER

Montageanleitung für TANDEM

Art. Nr. 08136-000/-500/-600

Der Umwelt zuliebe: wir drucken auf 100% Altpapier!



D

GB

F

NL

E

I

PL



FREIZEIT MARKE KETTLER

HEINZ KETTLER GmbH & Co. KG · Postfach 1020 · D-59463 Ense-Parsit

Read these instructions carefully before assembling the product or using it for the first time. They contain important information for your safety and for the correct use and maintenance of this KETTLER product. Keep the instructions in a safe place for information or for ordering spare parts.

This KETTLER product has been designed in accordance with the latest standards of safety and subjected to constant quality monitoring. The data gained from this quality process is then incorporated in the development of our products. For this reason, we reserve the right to make changes in design and technology in order to offer our customers products of the highest standard of quality at all times. In spite of this, should you have any ground for complaint, please contact your KETTLER dealer.

For your safety

- **Attention:** An adult should always supervise playing. Only one child may use this product (exception: the tandem seat). Do not use the wheeled toy near slopes, steps, roads, railways, lakes and rivers, etc. Sturdy footwear should be worn at all times. We recommend wearing suitable protective clothing and a safety helmet.
- This toy is designed only for private use (no commercial or public use).
- This child's wheeled toy conforms to the stipulated safety regulations European standard EN 71-1/2/-3 („Safety regulations for childrens toys“; max. weight of user: 50 kg). Incorrect repairs or alterations (removal of original parts or addition of other parts etc.) may be a source of danger to the user.
- This product may only be used for the intended purpose, i.e. as a wheeled toy to be used by one (1) child. All other use is not permitted, and possibly dangerous. The manufacturer cannot be held responsible for damages caused by improper use.
- Damaged parts may endanger the user and shorten the life span of the product. Please check all parts regularly, in short intervals according to use, for possible damages and loose connections (screws, plug-in connections).
- Damaged or worn parts must be replaced straight away and the vehicle must be withdrawn from use until repaired. If required please only use original KETTLER spare parts.
- Please ensure that the vehicle will only be used for playing when assembly has been carried out correctly, and checked, by an adult.
- Although there is practically no danger to children when using the vehicle according to its intended purpose, you should always supervise play activities.
- As the product is only a toy it should not be used on public roads, because it does not conform to the road traffic regulations.
- Please bear in mind that there is always a danger of children injuring themselves (falling off, tipping over etc.) whilst using swings, climbing frames, tricycles or similar equipment.
- Do not connect this toy to any other product; because this child's wheeled toy has not been designed for higher speeds.
- Please bear in mind that children are very often not able to judge their own capabilities and certain (dangerous) situations. Also consider that a natural urge to play plus their temperament may lead children into unforeseen situations for which the manufacturer cannot be held responsible.
- Please ensure that the wheeled toy is only used in surroundings free of danger.
- This wheeled toy does not have lights. It is dangerous to use it in the dark.
- ⚠ **Caution:** While assembly of the product keep off children's reach (Choking hazard - contains small parts).

Handling

- Before use always check that all screws and plug-in connections and respective safety devices fit correctly.
- Instruct children in the correct use of the product, and draw their attention to possible dangers.
- Sturdy, closed footwear must be worn when using this product.
- Please note that pedals on any wheeled toy without freewheeling appliance will turn even if the product is being pushed or is coasting.
- This wheeled toy does not have a so-called parking brake. Therefore secure the vehicle against rolling away. Do not leave children, who are not old enough to use the wheeled toy, unattended on a product.
- If this product can be adjusted please adapt it to your child's height.
- Do not transport anything on this product.
- Never use corrosive or abrasive substances to clean the toy. Never use substances which may cause pollution of the environment.
- Lubricate the bearing sleeves of the wheels and the handlebars with a few drops of oil every two or three months.
- For models with pneumatic tyres: When leaving wheeled toys with pneumatic tyres on floors containing solvents or which have been glued with such solvents (e.g. PVC) they may possibly stain it due to a chemical reaction with the natural product caoutchouc. If in doubt place something underneath the wheels. Ensure that air pressure in the tyres is correct (2,5 bar); if air pressure is too low this increases wear, and makes riding the toy more difficult!
- For models with push bars: Always ensure that the push bar fits correctly in the adaptor, and locks. Do not hang any weights on the bar! The vehicle may tip over, and your child may be hurt. The push bar is intended for adult use only, do not pass responsibility for children on to other children. For free play time take the push bar off for safety reasons.

Assembly of the toy vehicle

- The toy vehicle must be assembled carefully by an adult person. Study the assembly instructions carefully before beginning work. Assemble the vehicle in the exact sequence shown by the letters in the diagrams. This is essential for the safe function and use of the toy vehicle.
- Please note that there is **always** a danger of injury when working with tools or doing manual work. Therefore please be careful when assembling this machine.
- Ensure that your working area is free of possible sources of danger, for example don't leave any tools lying around. Always dispose packaging material in such a way that it may not cause any danger. There is always a **risk of suffocation** if children play with plastic bags!
- Bolt all the parts together loosely at first, and check that they have been assembled correctly. Tighten the locknuts by hand until resistance is felt, **then use spanner to finally tighten nuts completely against resistance (locking device)**. Then check that all screw connections have been tightened firmly. **Attention:** once locknuts have been unscrewed they no longer function correctly (the **locking device is destroyed**), and must be replaced.
- When assembling plastic grips: The grips can be pushed onto the handlebars more easily if they are first soaked in warm water.
- For technical reasons, we reserve the right to carry out preliminary assembly work (e.g. addition of tubing plugs).

List of spare parts page 27

When ordering spare parts, always state the full article number, spare-partnumber, the quantity required and the S/N of the product (see handling).

Example order: Art. no. 08136-000-500-600 / spare-part no. 91670058 / 1 pieces / S/N

Please keep original packaging of this article, so that it may be used for transport at a later date, if necessary.

Goods may **only** be returned after prior arrangement and in (internal) packaging, which is safe for transportation, in the original box if possible.

It is important to provide a detailed defect description / damage report!

Important: spare part prices do not include fastening material; if fastening material (bolts, nuts, washers etc.) is required, this should be clearly stated on the order by adding the words „**with fastening material**“.

Waste Disposal

KETTLER products are recyclable. At the end of its useful life please dispose of this article correctly and safely (local refuse sites).


**KETTLER (GB) Ltd. · KETTLER House, Merse Road · North Moons Moat · Redditch,
Worcestershire · B 98 9 HL · Great Britain**

**KETTLER International Inc. · 1355 London Bridge Road · Virginia Beach · Virginia
VA 23453 USA**
<http://www.kettler.de>









Messhilfe für Verschraubungsmaterial

GB Measuring help for screw connections
F Gabarit pour système de serrage
NL Meethulp voor schroefmateriaal

E Ayuda para la medición de los tornillos
I Misura per i materiali di avvitamento
PL Wzornik do połączeń śrubowych



Checkliste


| | | |
|---|---|--|
|  | 1 | |
|  | 1 | |
|  | 1 | |
|  | 1 | |
|  | 2 | |
|  | 1 | |
|  | 2 | |
|  | 2 | |

M 12

M 6 x 32

M 6 x 16

1




2




3




4



5



Ersatzteilzeichnung



Ersatzteilliste

| | | | 08136-000 | 08136-500 | 08136-600 |
|------|--------------------------------------|-----|---------------|---------------|---------------|
| Pos. | Bezeichnung | Stk | Ersatzteilnr. | Ersatzteilnr. | Ersatzteilnr. |
| 1 | Grundrahmen mit Bef.-Mat. für Pedale | 1 | 91610733 | 91610734 | 91610733 |
| 2 | Führungsbuchse | 1 | 70128425 | 70128425 | 70128425 |
| 3 | Pedal mit Bef.-Mat. für ø8mm | 2 | 70121541 | 70121541 | 70121541 |
| 4 | Lenker | 1 | 91650213 | 91650209 | 91650213 |
| 5 | KS-Griff mit Kugel | 2 | 10111023 | 10111023 | 10111023 |
| 6 | Blassitz 3534 | 1 | 70120242 | 70120241 | 70120242 |
| 7 | Griffschraube M12 | 1 | 91670058 | 91670058 | 91670058 |
| 8 | Sicherungskappe | 1 | 70121435 | 70121435 | 70121435 |
| 9 | Schraubenbeutel (o. Abb.) | 1 | 91680213 | 91680213 | 91680213 |



FREIZEIT MARKE KETTLER

