

BLADE MILL SPARE PARTS

IMPORTANT INFORMATION:

McLanahan Corporation recommends that you keep certain replacement parts at your facility. These parts will be available in the event of a breakdown and will also be available to perform any repairs that must be made as a result of regularly scheduled maintenance checks. **McLanahan Corporation** stocks a wide variety of commonly used components; however storing these parts at your facility will eliminate the expense of air-freighting critical parts that may be required during a breakdown situation. Contact the Parts Department at **McLanahan Corporation** for price and availability of all parts for your McLanahan equipment.

RECOMMENDED STANDARD SPARE PARTS:

<u>QUANTITY</u>	<u>DESCRIPTION</u>
1	Pillow Block Bearing Housing
1	Pillow Block Bearing
1	Lower Bearing Assembly Rebuild Kit
1	Seal Installation Tool
1	Wear Collar
1	Set V-Belts (Highly Recommended)
1	SetWearShoes & Fasteners (Optional)
1	SetPaddles & Fasteners (Optional)

Please contact our Parts & Service Department for current Pricing and Lead Times.