

ROTARY COAL BREAKER

IMPORTANT INFORMATION:

McLANAHAN CORPORATION recommends that you keep certain replacement parts at your facility. These parts will be available in the event of a breakdown and will also be available to perform any repairs that must be made as a result of regularly scheduled maintenance checks. **McLANAHAN CORPORATION** stocks a wide variety of commonly used components; however storing these parts at your facility will eliminate the expense of air-freighting critical parts that may be required during a breakdown situation. Contact the Parts Department at **McLANAHAN CORPORATION** for current price and availability of all parts for your McLanahan equipment.

RECOMMENDED STANDARD SPARE PARTS:

QUANTITY	DESCRIPTION
2	Trunnion Roller Assembly
2	Trust Roller Assembly
2	Graphite Scraper Block
5	Feed End Shell Liner
30	Flat Head Socket Capscrew,
30	Grip Nut, 3/4"
10	Screen Plate
60	Flat Head Socket Capscrew,
60	Lock Washer, 1"
60	Grip Nut, 1"
5	Lifter
15	Hex Head Capscrew, 1" x 5-
15	Lock Washer, 1"
15	Grip Nut, 1"
1	Cylinder Sprocket, 110-Tooth,
48	Hex Head Capscrew, 1" x 4-
48	Lock Washer, 1"
48	Grip Nut, 1"
1	Drive Sprocket, 16-Tooth
2	Socket Head Setscrew, 7/8" x
141	Roller Chain, 4.063" Pitch
1	Fluid Coupling Assembly
1	Liner, Dust Housing
20	Flat Socket Head Capscrew,
20	Grip nut, 5/8"
1	Lubrication Pump

1	Printed Circuit Board, Lubrication Pump
1	Power Supply Board, Lubrication Pump

- **The quantities shown for each of the following components are those utilized on the machine identified above and may not reflect quantities recommended be purchased and held for spare parts support.**

Please contact our Parts & Service Department for current Pricing and Lead Times.