

STALL FILLER SPARE PARTS

IMPORTANT INFORMATION:

McLanahan Corporation recommends that you keep certain replacement parts at your facility. These parts will be available in the event of a breakdown and will also be available to perform any repairs that must be made as a result of regularly scheduled maintenance checks. **McLanahan Corporation** stocks a wide variety of commonly used components; however storing these parts at your facility will eliminate the expense of air-freighting critical parts that may be required during a breakdown situation. Contact the Parts Department at **McLanahan Corporation** for price and availability of all parts for your McLanahan equipment.

RECOMMENDED STANDARD SPARE PARTS:

<u>QUANTITY</u>	<u>DESCRIPTION</u>
1	DISCHARGE CONVEYOR IDLER SHAFT ASSEMBLY
1	DISCHARGE CONVEYOR TAIL SHAFT ASSEMBLY
1	DISCHARGE CONVEYOR DRIVE SHAFT ASSEMBLY
1	DISCHARGE CONVEYOR BELT
1	DISCHARGE CONVEYOR SKIRT BOARD (FRONT)
1	DISCHARGE CONVEYOR SKIRT BOARD (BACK)
2	DISCHARGE CONVEYOR DRIVE SPROCKET (OUTER)
2	DISCHARGE CONVEYOR DRIVE SPROCKET (INNER)
3	DISCHARGE CONVEYOR IDLER WHEEL
2	DISCHARGE CONVEYOR DRIVE FLANGE BEARING
1	HYDRAULIC SPIN-ON FILTER
1	FEED CONVEYOR BELT
1	FEED CONVEYOR RUBBER SKIRT BOARD KIT

Please contact our Parts & Service Department for current Pricing and Lead Times.