


Woodsmith® PLANS

Shop Drawings




Multipurpose Layout Tool


EDGE GUIDE TOP PLATE




EDGE GUIDE FENCE




END VIEW





PENCIL HOLDER




NUT PLATE




PENCIL HOLDER




PIVOT TOP PLATE




PIVOT BOTTOM PLATE




CIRCLE DISC



ADD 1/4 INCH PIN




PENCIL MARKER





LEE VALLEY 1 INCH
KNOB (00M55.01)



ADD 1/4-20 x 1/2 STUD



TEE SLOT NUT
(LEE VALLEY 05J21.15)



NOTE: USE LEE VALLEY 1/4-20 TEE
SLOT TRACK (12K79.22)
OR THE EQUIVALENT