



Liberty Furniture
INDUSTRIES, INC


ASSEMBLY INSTRUCTION


DESCRIPTION: ENTERTAINMENT TV STAND

ITEM# : **244-TV70**


Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts List Below:

PARTS LIST:



①			②	
TV STAND: 1PC	HARDWARE LIST			
	NO.	Drawing	Description	Q'ty
	A		Furniture Tipping Restraint	1 Set

HOW TO REMOVE DRAWER



CLEANING INSTRUCTION

Clean the TV Stand surface with a furniture polish and a soft cloth.

Made inVietNam



Liberty Furniture
INDUSTRIES, INC


ASSEMBLY INSTRUCTION



DESCRIPTION: LEFT PIER



ITEM# : **244 - EL00**

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts List Below:

PARTS LIST:



① 	② 	③	HARDWARE LIST			
			NO.	Drawing	Description	Q'ty
			A		Furniture Tipping Restraint	1 Set
LEFT PIER UNIT: 1PC	GLASS SHELF: 1PC					



CLEANING INSTRUCTION

Clean the Left Pier surface with a furniture polish and a soft cloth.

Made inVietNam



Liberty Furniture
INDUSTRIES, INC


ASSEMBLY INSTRUCTION


DESCRIPTION: RIGHT PIER



ITEM# : **244 - ER00**

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts List Below:

PARTS LIST:



① 	② 	③			
		HARDWARE LIST			
RIGHT PIER UNIT: 1PC	GLASS SHELF: 1PC	NO.	Drawing	Description	Q'ty
		A		Furniture Tipping Restraint	1 Set



CLEANING INSTRUCTION

Clean the Right Pier surface with a furniture polish and a soft cloth.

Made inVietNam




ASSEMBLY INSTRUCTION






DESCRIPTION: ENTERTAINMENT HUTCH
ENTERTAINMENT TV STAND
LEFT PIER
RIGHT PIER

ITEM# : **244 - EL00/ER00/EC00/TV70: WALL UNIT**





Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts List Below:



HUTCH PART LIST:

① 	② 
LIGHT BRIDGE: 1PC	ADJUSTABLE SHELF: 1PC
③ 	④ 
LEFT SIDE FRAME: 1PC	RIGHT SIDE FRAME: 1PC
⑤ 	⑥ 
CENTER POST BACK: 1PC	BOTTOM RAIL BACK: 1PC
⑦ 	⑧ 
LEFT BACK PANEL: 1PC	RIGHT BACK PANEL : 1PC

PARTS LIST:

	 PIER TOP GLASS SHELF : 1PC		 PIER TOP GLASS SHELF : 1PC
LEFT PIER UNIT : 1PC		RIGHT PIER UNIT : 1PC	
			
TV STAND: 1PC			


HARDWARE LIST

NO.	Drawing	Description	
A		Bolt Ø1/4"x1-1/4"	4pcs
B		Flat washer (Ø1/4"x16mm)	4pcs
C		Spring washer (Ø1/4")	4pcs
D		Shelf support	6pcs
E		Cover cap plastic(Ø20xØ18x7mmH)	4pcs
F		Wood screw(Ø8*3/4")	34pcs
G		Wood screw(Ø8*3/4")	6pcs
H		Wood screw(Ø6*5/8")	6pcs
I		Wood screw(Ø8*1-1/4")	6pcs
J		Allen wrench (4mm)	1pc


CLEANING INSTRUCTION

Clean the wall unit surface with a furniture polish and a soft cloth.


STEP1




STEP2



STEP 3



STEP 4




CLEANING INSTRUCTION


Clean the wall unit surface with a furniture polish and a soft cloth.

STEP 5

HOW TO REMOVE DRAWER



STEP 6



CLEANING INSTRUCTION

Clean the wall unit surface with a furniture polish and a soft cloth.

Made in VietNam