




ITEM#: 417-BR36


DESCRIPTION: SLIDING DOOR DRESSER

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts list below.

FINISH ASSEMBLY





No.	Drawing	Description	Q'ty
A		Tipping Restraint	1




STEP 1

Furniture Tipping Restraint must always be used to prevent the furniture from tipping





Push tab down to remove drawer




Push tab up to remove drawer

To remove drawer, simultaneously pull tab up on one side and push tab down on the other side and remove drawer.



NOT INCLUDED



LEVELER