

Assembly instructions for MIRROR & DRESSER CN600DR

Caution : Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.

1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
3. Please do not over tighten screw or bolts.
4. Please put all parts on non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

Part List			
No.	Descriptions	Code	Qty
A	Dresser	CN600DR	1Pc
B	Front Legs (Packed Inside Dresser)	PCN600CLF	2Pcs
C	Back Left Leg (Packed Inside Dresser)	PCN600CLBR	1Pc
D	Back Right Leg (Packed Inside Dresser)	PCN600CLBL	1Pc
E	Center Support Leg (Packed Inside Dresser)	PCN600DSPL	1Pc

Hardware List (Packed Inside Dresser)			
NO.	Description	Code	Qty.
1	JCBC Screw M6 x 38mm	PCN600LGHW	8Pcs
2	Spring Washer 1/4"		8Pcs
3	Flat Washer 1/4" x 19mm(Outer)		8Pcs
4	Allen Key		1Pc
5	Tipping Restraint	PCN600ATKT	1 Set

