







Assembly Instruction for DINING SOFA W/ SEVEN PILLOWS DMD140SFTS

Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.


1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
3. Please do not over tighten screws or bolts.
4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

PART LIST FOR SOFA			
No.	PART DESC	CODE.	Q'TY
A	DINING SOFA - BACK FRAME WITH CUSHION		1
B	DINING SOFA - SEAT FRAME WITH CUSHION		1
C	DINING SOFA - LEGS	PDMD100SFCRLEG	4
D	DINING SOFA - MIDDLE LEGS W/ LEVELER	PDMD140SFTSLEG	2
E	DINING LOVE SEAT W/SEVEN PILLOWS - WHITE PILLOW	PDMD100SFCRPIL1	4
F	DINING LOVE SEAT W/SEVEN PILLOWS - CROSS PILLOW	PDMD100SFCRPIL2	3


HARDWARE LIST PACKED INSIDE BOX			
No.	HARDWARE DESC	CODE.	Q'TY
1	 ALLEN BOLT (Ø5/16"*1-3/4")	PDMD140SFTSHW	10
2	 ALLEN BOLT (Ø5/16"*2-3/8")		8
3	 SPRING WASHER (Ø5/16")		18
4	 FLAT WASHER (Ø5/16")		18
5	 ALLEN KEY (Ø1/8")		1

 Only tighten all bolts when all bolts aligned with bolt inserts.

STEP:1



STEP:2



COMPLETED

