


Assembly Instruction for (D680-33) FOLDING TOP DINING TABLE BEACH/ NATURAL METAL LCL100FTDT


Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.

1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
3. Please do not over tighten screws or bolts.
4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.


PARTS LIST:				
NO.	DESCRIPTION	SKETCH	PART CODE	QTY
A	Table Top		PLCL100FTDRTOP	1
B	Leg		PLCL100FTDTLEG	2
C	Stretcher		PLCL100FTDTSTR1	2

HARDWARE LIST:				
NO.	DESCRIPTION	SKETCH	PART CODE	QTY
1	Bolt (5/16 x 2")		PLCL100FTDTHW	8
2	Bolt (5/16 x 1 2/5")			2
3	Bolt (5/16 x 3/5")			4
4	Lock Washer (5/16 x 1/2" x 2mm)			14
5	Flat Washer (5/16 x 3/4" x 2mm)			14
6	Wrench			1


Step 1



Step 2



Step 3



Step 4

