



Assembly Instruction for
COFFEE TABLE
TPR350CT

- Caution: Please read instructions thoroughly before unpacking assembly parts. Sharp, exposed staple tips can cause injury, therefore, for your protection, please remove any exposed staples used in packing.
1. We recommend that you should assemble this product with the assistance of another person; this will make assembly easier, and will help to eliminate damage to the product or injury to persons during assembly.
 2. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.
 3. Please do not over tighten screws or bolts.
 4. Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.


PART LIST FOR COFFEE TABLE TABLE				HARDWARE LIST PACKED INSIDE BOX			
No.	PART DESC	CODE.	Q'TY	No.	HARDWARE DESC	CODE.	Q'TY
A	COFFEE TABLE - TABLE TOP		1	1	ALLEN BOLT (Ø5/16**1-3/4")	PTPR350CTHW	12
B	COFFEE TABLE - CURVED LEG	PTPR350CTLEG	4	2	SPRING WASHER (Ø5/16")		12
C	COFFEE TABLE - BASE	PTPR350CTBASE	1	3	FLAT WASHER (Ø5/16")		12
D	COFFEE TABLE - SHELF	PTPR350CTSHF	1	4	ALLEN KEY (Ø1/8")		1
				5	ALLEN KEY (Ø1/8**3")		1

 Only tighten all bolts when all bolts aligned with bolt inserts.

STEP:1*Do not tighten all bolts until final step




STEP:2




STEP:3

Adjust the glass end to balance with the foot according to the sticker on the glass head.
Remove sticker after assemble done.



COMPLETED

*Note: Shelf and base veneer should be same grain.



*Note: Shelf and base veneer should be same grain.