


B3399 Bryant Sectional | Components & Configurations


Leather Furniture

Components


LAF = Left-Arm-Facing
RAF = Right-Arm-Facing




B3399-33
LAF Corner Sofa




B3399-34
RAF Corner Sofa




B3399-37
LAF Sofa




B3399-38
RAF Sofa




B3399-27
LAF Loveseat




B3399-28
RAF Loveseat




B3399-29
Armless Loveseat




B3399-255
LAF Angled Chaise




B3399-265
RAF Angled Chaise




B3399-23
Full Wedge




B3399-231
Corner Chair




B3399-25
LAF Chaise




B3399-26
RAF Chaise



B3399-17
LAF Chair



B3399-18
RAF Chair



B3399-19
Armless Chair

Scale 1/4"=1'


Dimensions are in inches and are subject to variance.
© Flexsteel Industries, Inc. 6/22
FLX-CP-FS-CC-B3399

FLEXSTEEL®

B3399 Bryant Sectional | Components & Configurations

Leather Furniture

Sample Configurations



Scale 1/4"=1'

Dimensions are in inches and are subject to variance.
© Flexsteel Industries, Inc. 6/22
FLX-CP-FS-CC-B3399

FLEXSTEEL®