

Battery Configuration Reference Chart:

Model #	VDC	Amp/Hr	A	B	C
BT1212	12VDC	12	3.75"	5.94"	3.5"
BT124	12VDC	4	2.76"	3.5"	4"
BT1240	12VDC	40	6.5"	7.72"	6.73"
BT126	12VDC	7	2.56"	5.94"	3.66"


Installation Instructions:

1. Place Rechargeable Battery in enclosure.
2. Connect battery to power supply. Battery voltage must match power supply voltage.

Note: Be careful to observe polarity.

WARNING: This installation should be made by qualified service personnel and should conform to all local codes and in accordance with the National Electrical Codes.

Fig. 1



Altronix is not responsible for any typographical errors. Product specifications are subject to change without notice.