

S-41 AND S-41-R  
INSTRUCTIONS FOR MOUNTING HOSE IN  
SEMI—AUTOMATIC HOSE RACK

1996

1. Attach female coupling to nipple.
2. Fold hose 9" from coupling, and insert fold between rack and pressure bar as shown.
3. Holding pressure bar against hose, run hose over lock cam. Push cam up against hose to hold pressure bar in place. Remove slack hose between bar and cam and tighten support-pin securely.
4. Check to see if hose is clamped tight by pulling down on hose.
5. Place remaining folds of hose on pins.
6. Place tip end of nozzle in nozzle clip on front of rack.

Operation:

With hose properly installed, valve may be opened without water passing beyond pressure bar. Water will be released after last loop of hose is pulled from rack.

