

CRL Glove Sizing

All glove sizes vary depending upon their style. Nitrile gloves for instance, require a skin tight fit. On the other hand, general purpose work gloves or glass handling gloves need not fit too tight or too loose. Measure around the palm of your hand, and use the chart to the right to get the correct fit.

- **What Size Glove Should You Order?**
- **Use the Chart Below to Determine the Correct Size**

SIZE	PALM MEASUREMENT
Small	7" to 8" (178 to 203 mm)
Medium	8" to 9" (203 to 229 mm)
Large	9" to 10" (229 to 254 mm)
X-Large	10" to 11" (254 to 279 mm)



Measure around your palm