#### Model RTS76 - DISCONTINUED

Non handed

Sized spring

Identified by # on case

Hold Open or No Hold Open (90/105)



#### Model RTS85

Non handed

Sized spring - Standard: size 3

Identified by # on case -

Hold Open or No Hold Open (90/105)



### Model RTS88

Non handed

Sized spring - Standard: size 3

Identified by # on case

over 3'-6" to 4'-0"

Hold Open or No Hold Open (90/105)



## **Dummy Pivots**

Available in all 3 RTS Series models

Non handed

No spring power. Pivot only.

	- /2		
Size Selector Chart RTS88 Series			
Maximum Door Width		Closer	
Interior	Exterior	Size	
to 3'-0"	to 2'-6"	2	
over 3'-0" to 3'-6"	over 2'-6" to 3'-0"	3	

over 3'-0" to 3'-6"

Size Selector Chart RTS88 BFI/BFE		
Door Width		Barrier-Free
Interior	Exterior	Closer
3′-0″ ₺	_	RTS88 BFI
_	3′-0″ ₺	RTS88 BFE

# Model 3-5 Non handed Sized spring Identified by # on end of closer

Model 40

Non handed

Sized spring

Identified by # on bottom of case

