


F-XX-V surface vertical rod exit device

Fire



| No. | Qty. | Part No. | Description | Notes |
|-----|------|----------|------------------------------------------------------------------------|-------|
| 1 | 1 | 3747 | XX Lever Arm LH | A |
| 2 | 1 | 3767 | XX Crossbar | A |
| 3 | 1 | 3746 | XX Lever Arm RH | A |
| 4 | 2 | 660025 | 1/4-20 x 1/2" Crossbar Retaining Screw | |
| 5 | 1 | 600140 | Center Case Cover Mounting Package (US32D) | |
| 6 | 1 | 650134 | F-XX-V Mounting Package | |
| 7 | 2 | 3749 | XX Series Lever Arm Axle | |
| 8 | 1 | 060121 | Latch Cover Screw package of 10 (specify by finish: US4, US10B, US32D) | |
| 12 | 1 | 3742 | F-XX Series Center Case Cover | A |

| No. | Qty. | Part No. | Description | Notes |
|-----|------|----------|------------------------------------|-------|
| 16 | 1 | 3741 | XX Series End Case Cover | A |
| 17 | 1 | 684 | F-XX Series End Case Assembly | |
| 19 | 2 | 610214 | F-XX Axle Support Housing Assembly | |
| 25 | 1 | 3566 | Locking Cam Operator | |
| 27 | 1 | 660439 | Retaining Ring | |
| 28 | 1 | 3775 | XX-R Knob Cam | B |
| 30 | 1 | 687 | F-XX-V-EO Center Case | |
| | | F582 | F-XX-V-K/L Center Case | |
| | | F583 | F-XX-V-TP Center Case | |
| 33 | 1 | 3762 | Locking Cam | |

A Specify by finish: SP313, US3, US4, US10, US26, US26D, US32, US32D
 B K/L function only.