


Button-fix™ Panel Connecting Fittings

→ Button



- > To be used in conjunction with any of the Fixes
- > Material: Plastic

Color	Mounting	Item No.
green	countersunk wood screw	262.94.030
orange	euro screw	262.94.031

Note Order screws separately.


→ Fix Marker Tool



- > To be used in conjunction with Button-fix™ type 2
- > Quickly and accurately align the Button-fix™ installation without measuring
- > The marker will leave indents in the mating panel surface which can be used as a guide
- > L x W: 50 x 25 mm
- > Material: Plastic

Color	Item No.
red	002.84.751

→ Safety Cord



- > To be used in conjunction with Button-fix™ type 2
- > An additional button is used to capture the loop on the safety cord, installed adjacent to the fixing button
- > The loop on the safety cord must be manually eased off the button to remove the panel
- > Install 2 safety cords on a vertical panel
- > Material: Plastic

Color	Item No.
black	262.94.025

Note Button must be ordered separately.

→ Button Marker Tool



- > To be used in conjunction with Button-fix™ type 1
- > Quickly and accurately align the Button-fix™ installation without measuring
- > The marker will leave indents in the mating panel surface which can be used as a guide
- > Ø: 18 mm
- > Material: Plastic

Color	Item No.
red	002.84.750

→ Multi Jig



- > Designed to help mortise Button-fix™ Type 1, Type 1 Bonded and Type 1 Flush Fix
- > For use with a metric 12 mm cutter and a 30 mm guide brush
- > Material: Plastic

Item No.
002.84.752

Supplied With

Magnetic steel plate – creates an oval mortise for Type 1 and Type 1 Bonded Fixes. Square plates can be oriented vertically or horizontally in the frame.

Magnetic steel plate – creates an oval mortise for Type 1 Flush Fix. Square plates can be oriented vertically or horizontally in the frame.

Varianta screws	page 12.16
Flat head screws	pages 12.7-12.8, 12.10, 12.13