
Lid and Flap Stays

HAFELE


Salice Pacta

ightarrow Cover Caps




Installation

1.



2.



Adjustment facility

- 1 Depth adjustment
- 2 Side adjustment
- 3 Height adjustment

> Material: Plastic


Color	Item No.
gray	365.13.520
white	365.13.720
black	365.13.320

Supplied With

2 pcs.



Fixing the safety lock screw.




Inserting the soft opening mechanism.


Slide front of soft opening mechanism onto the designated axle and clip-in. Tools are not required.

68 (2 11/16")


5.




Clip soft opening mechanism into rear axle.




Clip cover housing onto hinge arm and then onto cup.





Disassembly





- 1 Lift flap
- 2 Remove soft opening mechanism.
- 3 Loosen safety lock screw.
- Remove hinge arm from mounting plate by applying pressure onto clip of mounting plate from above.

9