

838S INSTALLATION INSTRUCTIONS

ASTRALGAL AND MEETING STILES

Fasten with nails through pile and backing.

Note: Pile and backing do not separate.

