

THRESHOLDS - COVER PLATES

Cover Plates are used primarily to cover expansion joints and for situations requiring extra width or strength. Manufactured from solid cold rolled aluminum for extra durability.

Fasteners: Furnished without holes and fasteners unless specified

Notes:

- Available to 96" in length
- Furnished with both edges beveled

676S



Finishes:

Certifications:

MIL



677S



Finishes:

Certifications:

MIL




THRESHOLD ANCHORS

Threshold Anchors provide a fully adjustable anchor for concrete installation. Special locking nut assemblies can be positioned to accommodate various mounting hole spacings.

Order: Specify 1/4"-20 mounting holes for any threshold intended for use with the 619S

Fasteners: 1/4"-20 flat head screws and locking nut assembly per foot of anchor

619S



Finishes:

MIL

