





Arm assemblies swing door & folding applications

4.041d9 8/23/11

C5686Connection for
1/2" glass**C5686-1**Connection for
3/4" glassC5254-1 is
required when
ordering one of
these connections
note: discard the
foot and mounting
screws**C5254-A/B/C/1P/1Q/1R/1S
CONNECTING ARM
ASSEMBLY**C3080-48
48 tooth (in)
60 tooth (out)**C4250-48 A/B/C/P/Q/R/S
INSWING ARM ASSEMBLY**

For 48 tooth output shaft and 60 tooth arm

C4193-1
60 toothC3080-48
48 tooth (in)
60 tooth (out)**C4252-48 A/B/C/P/Q/R/S
OUTSWING ARM ASSEMBLY**



For 48 tooth output shaft and 60 tooth arm

C4195-1
60 tooth**C4250-1 A/B/C/P/Q/R/S
INSWING ARM ASSEMBLY**


For 14 tooth output shaft

C4193-3
14 tooth**C4252-1 A/B/C/P/Q/R/S
OUTSWING ARM ASSEMBLY**


For 14 tooth output shaft

C4195-4
14 tooth**EXTENDED SWING DOOR ARMS**C4411-1A/B
14 Tooth**C4236-1 A/B/C/P/Q/R/S
INSWING ARM ASSEMBLY**


For 14 tooth output shaft

C4411-A/B
60 ToothC3080-48
48 tooth (in)
60 tooth (out)**C4236-48 A/B/C/P/Q/R/S
INSWING ARM ASSEMBLY**


For 48 tooth output shaft and 60 tooth arm

C4411-2A/B
14 Tooth**C4238-1 A/B/C/P/Q/R/S
OUTSWING ARM ASSEMBLY**

For 14 tooth output shaft

C4410-A/B
60 ToothC3080-48
48 tooth (in)
60 tooth (out)**C4238-48 A/B/C/P/Q/R/S
OUTSWING ARM ASSEMBLY**

For 48 tooth output shaft and 60 tooth arm

**C5254-3
EXTENDED CONNECTING ARM
ASSEMBLY**