

Template
Number:

829122-00(2)

Date:


09/01/99

Description:



AA & BB Invisible Latch &
AP2 Auxiliary Pusher Installation Template

GLYNN-JOHNSON.
Door Control Products

Type AA Latch




Type BB Latch



AP2 Auxiliary Pusher Installation Template

When Latch is installed on doors or panels where a vacuum condition exists and it is difficult to open door, install GJ Auxiliary Pushers.



Installation Instructions:

1. Install Latch Case (See note 1).
2. Remove screws from latch & attach metal template as shown for locating screws (See note 2). Close door gently against prongs, marking locations for screws. Remove plate.
3. Install Hook on door.
4. Reinstall the Latch Case.

Operation Instructions:

- To lock, push door back to flush position.
- To release, push door against stop and release.

Notes:

1. 3/16" (5mm) clearance between door & stop is necessary to insure proper operation of latch.
2. Be sure the prongs of metal template point away from latch.

	Qty.	
AA Body	3	6 x 1" RPHSMS
BB Body	4	6 x 1 1/4" RPHSMS
Strike	2	6 x 3/4" FPHSMS
AP2	2	6 x 3/4" FPHSMS