








ORIENTATION OF THE BACK PLATE GEAR ASSEMBLY  
FOR R.H.R.B. DOORS      FOR L.H.R.B. DOORS









1095 RIM EXIT DEVICE



| ASSEMBLY<br>NO. | PART NO.   | DESCRIPTION                                 | FINISH                           |
|-----------------|------------|---------------------------------------------|----------------------------------|
| 1               | 30-988     | RIGHT BODY & ARM ASSEMBLY - ACTIVE - RHRB   | US28 / 628<br>DBZ 313<br>BLK 335 |
| 2               | 30-989     | LEFT BODY & ARM ASSEMBLY - ACTIVE - LHRB    | US28 / 628<br>DBZ 313<br>BLK 335 |
| 3               | 30-990     | LEFT BODY & ARM ASSEMBLY - INACTIVE - RHRB  | US28 / 628<br>DBZ 313<br>BLK 335 |
| 4               | 30-991     | RIGHT BODY & ARM ASSEMBLY - INACTIVE - LHRB | US28 / 628<br>DBZ 313<br>BLK 335 |
| 5               | 30-1247    | RIGHT ARM ASSEMBLY - ACTIVE - RHRB          | US28 / 628<br>DBZ 313<br>BLK 335 |
| 6               | 30-1248    | LEFT ARM ASSEMBLY - ACTIVE - LHRB           | US28 / 628<br>DBZ 313<br>BLK 335 |
| 7               | 30-1242    | LEFT ARM ASSEMBLY - INACTIVE - RHRB         | US28 / 628<br>DBZ 313<br>BLK 335 |
| 8               | 30-1243    | RIGHT ARM ASSEMBLY - INACTIVE - LHRB        | US28 / 628<br>DBZ 313<br>BLK 335 |
| 9               | 30-1115    | DOGGING PIN ASSEMBLY                        |                                  |
| 10              | 30-851     | BODY HARDWARE PACKAGE                       |                                  |
| 11              | 30-846     | BACK PLATE SUB-ASSEMBLY - RHRB              | US28 / 628<br>DBZ 313<br>BLK 335 |
| 12              | 30-847     | BACK PLATE SUB-ASSEMBLY - LHRB              | US28 / 628<br>DBZ 313<br>BLK 335 |
| 13              | 30-852     | BACK PLATE HARDWARE PACKAGE                 |                                  |
| 14              | 30-733-PKG | CROSSBAR ASSEMBLY - 4/0                     | US28 / 628<br>DBZ 313<br>BLK 335 |
| 15              | 30-1117    | DOGGING PIN ASSEMBLY - THUMBTURN (Optional) | US28 / 628<br>DBZ 313<br>BLK 335 |

# 1095P RIM EXIT DEVICE - PADDLE

## ORIENTATION OF THE BACK PLATE GEAR ASSEMBLY FOR R.H.R.B. DOORS      FOR L.H.R.B. DOORS



| ASSEMBLY<br>NO. | PART NO. | DESCRIPTION                                 | FINISH                           |
|-----------------|----------|---------------------------------------------|----------------------------------|
| 1               | 30-998   | BODY & PADDLE ASSEMBLY - RHRB               | US28 / 628<br>DBZ 313<br>BLK 335 |
| 3               | 30-999   | BODY & PADDLE ASSEMBLY - LHRB               | US28 / 628<br>DBZ 313<br>BLK 335 |
| 5               | 30-1245  | PUSH PADDLE ASSEMBLY - RHRB                 | US28 / 628<br>DBZ 313<br>BLK 335 |
| 6               | 30-1246  | PUSH PADDLE ASSEMBLY - LHRB                 | US28 / 628<br>DBZ 313<br>BLK 335 |
| 9               | 30-1115  | DOGGING PIN ASSEMBLY                        |                                  |
| 10              | 30-851   | BODY HARDWARE PACKAGE                       |                                  |
| 11              | 30-846   | BACK PLATE GEAR ASSEMBLY - RHRB             | US28 / 628<br>DBZ 313<br>BLK 335 |
| 12              | 30-847   | BACK PLATE GEAR ASSEMBLY - LHRB             | US28 / 628<br>DBZ 313<br>BLK 335 |
| 13              | 30-852   | BACK PLATE HARDWARE PACKAGE                 |                                  |
| 15              | 30-1117  | DOGGING PIN ASSEMBLY - THUMBTURN (Optional) | US28 / 628<br>DBZ 313<br>BLK 335 |