LCN ILLUSTRATED PARTS LIST "Introduction"

How to Use the LCN Parts List

The *LCN Illustrated Parts List* is designed to help technical service or maintenance personnel correctly identify parts that may be required to return an LCN closer to service.

Parts List Organization

The *LCN Illustrated Parts List* identifies replacement parts that are available through many LCN distributors. The sections, in order, are the 4000 Series, the 1000 Series, the Fire/Life Safety Series, the High Security Series, & the Power Operator Series. Closers are listed in numerical order within each section. Major components such as cylinder assemblies, covers, arm assemblies, & track assemblies are listed within each individual closer series. Many times, a complete component assembly has individual replacement parts available.

Casting (Forging) Numbers

Many LCN parts or components have casting or forging numbers stamped or raised on the surface. An example would be the '71' or '320G' on an LCN cylinder assembly. These numbers really do not identify a particular part or component. You should follow the 'How to Order' page in the latest edition of the LCN Catalog or call LCN Customer Service for assistance.


Additional Information

In addition to the closer series, suffix number, and short description, many parts and components require more information. Items that require more information have letters listed to the right of the description. The letter(s) are defined as follows.

F – Finish. Indicate the powder coat or plated finish desired. Not all parts and components are available with a plated finish. Refer to either the latest edition of the LCN Catalog

or the current LCN Price List for a standard powder coat finish chart and available plated finish designations. A bright metallic (MTLPC) finish is also available. Bright metalic is a powder coat alternative to US26D. RAL custom finishes are also available.

- S Size. Refers to the spring power of the closer. The larger the number, the more power the closer may have to close a door. Several closer series have an adjustable 'size 1' available. In many cases, a 'size 1' closer will meet low opening force requirements. Some 'size 1' closers are not adjustable. Please refer to the latest edition of the LCN Catalog for clarification on individual closer spring power.
- H Hand. Please specify either RH (Right Hand) or LH (Left Hand). The hand of a door can be determined several ways. The latest edition of the LCN Catalog has an easy to use diagram that may be utilized as a reference.



V – Voltage. Some parts and components require voltage. Please specify either 24v or 120v.

Part and Component Pricing

Prices for parts and components listed with the *LCN Illustrated Parts List* can be found in the current LCN Price List. The Price List contains basic ordering & product information.



LCN ILLUSTRATED PARTS LIST "Introduction"

How to Order

- 1. Identify the closer series; 4110, 4040, 1460, 1520, 2030, 3130, 4310ME, etc.
- 2. Refer to the page(s) illustrating the service parts available for the specific closer and select the part required by using the closer series and the suffix.
- 3. Check to the right of the part description. If additional information is required, please provide it.
- 4. Order the parts required using the closer series, suffix number, finish, size, hand, and/or voltage.

Part or Component Identification

If the part you require is not shown in the *LCN Illustrated Parts List*, it may be obsolete. Contact your distributor, your local Security & Safety Consultants office or LCN Customer Service.

Ordering Examples

Here are a few examples of what an item may look like as it is ordered. Please refer to the 'How to Order' page at the end of each individual closer series within the LCN Catalog.

2310ME-3351 x On/Off Switch x 24v 4040SE-3038 x Track x AL x 120v 4020T-72MC x Metal Cover x RH x AL 4313ME-3971 x Cylinder x LH x AL x 24v 3130-3054 Hold Open Clip 4040-62PA x Parallel Arm Shoe x DKBRZ 4010-18 Plate x AL 1520-3077SCNS Arm x BRASS 2030-169 Bumper Assembly 4640-3462 Controller Assembly 7910-956 Actuator SEM7850-825 Door Armature Only

Trademarks

List of trademarks that may appear in the *LCN Illustrated Parts List*. This list includes but is not limited to the following:

Cush-n-Stop® Equalizer® Pacer® Quest®

Sentronic® Shield and Device®

Smoothee® Thriftee®

Super Stock® Super Smoothee®

Additional Assistance

If any additional assistance is needed, call LCN at (800) 526-2400. Our Customer Service or Technical Support Team will do their very best to offer door control solutions on any of the products listed within the *LCN Illustrated Parts List*.

Please note....

Every effort has been made to insure the accuracy of the LCN Illustrated Parts List. If an error does exist, please contact LCN Customer Service. Errors and omissions will be incorporated into the next edition of the LCN Illustrated Parts List. Illustrations are designed to show general shape and size of a part and the relationship that part has to other parts. Actual size and shape of parts or components may differ or vary from the actual part or component that is shipped. LCN offers this information as a reference only. All information is subject to change without notice from LCN. If any additional information is needed, please call LCN Customer Service or Technical Support at (800) 526-2400. You may also visit LCN on the web at www.lcnclosers.com.



LCN ILLUSTRATED PARTS LIST "Table of Contents"

		PAGE
	duction	
Table	e of Contents	3
4000 OF		
	RIES SURFACE MOUNTED CLOSER	
	Τ	
	Т	
4020		_
.000		
	Т	
	Τ	
	Γ	
	RIES SURFACE MOUNTED CLOSEF	
	RIES SURFACE MOUNTED CLOSER	
1070		1
1070 1370 1460		5 9
1070 1370 1460		5 9
1070 1370 1460 1460 1520	Τ	1 9 17 21
1070 1370 1460 1460 1520	Т	1 9 17 21
1070 1370 1460 1460 1520 1520	T	1 9 17 21
1070 1370 1460 1460 1520 1520	TT	1 9 17 21 27
1070 1370 1460 1460 1520 1520 CONCEA 330 .	T	1 9 17 21 27 PAGE
1070 1370 1460 1460 1520 1520 CONCEA 330 . 2010	T	1 9 17 21 27 PAGE 1
1070 1370 1460 1460 1520 1520 CONCEA 330 . 2010 2030	T	1 9 21 27 PAGE 1
1070 1370 1460 1460 1520 1520 CONCEA 330 . 2010 2030 3030	T	1 9 21 27 PAGE 1 5
1070 1370 1460 1460 1520 1520 CONCEA 330 . 2010 2030 3030 3130	T	12727 PAGE1335
1070 1370 1460 1460 1520 1520 CONCEA 330 . 2010 2030 3030	T	11 5 9 21 27 PAGEE 1 5 5

FIRE/LIFE SAFETY CLOSER/HOLDERS	
7800SEM	1
3130SE	3
4040SE	5
2310ME	9
4310ME	11
4410ME	13
4310HSA	15
4410HSA	17
SEH	19
HIGH SECURITY CLOSERS	
2210	1
2210DPS	
4210	
4210T	7
4510	
4510T	
POWER OPERATORS	
2610 Pneumatic	1
4630 Electric	
4640 Electric	
4810 Pneumatic	
4820 Pneumatic	
4840 Pneumatic	
7900 Control Boxes & Accessories	
1000 0011t101 D0/G3 & ACCG3301163	1 5 - 20



LCN ILLUSTRATED PARTS LIST



LCN 1070 SERIES

Discontinued

159

Cylinder Assemblies.

1071(4-5)-3071 Cylinder Assembly

Includes screw pack (WMS standard – please specify other)

Size '1' cylinder is adjustable from size 1-3

Individual Cylinder Parts_

Individual cylinder parts for 1071-3071

1070-159 Arm Screw F


Covers_ 1070-72 F Standard Cover

Individual Cover Parts_

Individual cover parts for 1070-72 1070-146 Shaft Cover

F


F, S





Discontinued

Complete Arm Assen	nblies		_
1070-3077	Regular Arm	F	
	Includes 1070-77, -79, -83, & -159		
1070-3077L	Long Arm	F	
	Includes 1070-77, -79LR, -83, & -159)	
1070-3077/PA	Regular Arm w/PA	F	
	Includes 1070-62PA, -77, -79, -83, 15	9, & -201	
1070-3077/62A	Regular Arm w/62A	F	3077
	Includes 1070-62A, -77, -79, -83, & -	159	3077L
Individual Arm Parts	,		- 62PA
_	or 1070-3077, -3077L, -3077/PA,	& -3077/62A	
1070-62A	Auxiliary Parallel Arm Shoe	F	
1070-62PA	Parallel Arm Shoe	F	201
	Includes 1070-201	_	201
1070-77	Main Arm & Forearm	F	3077/PA
	Includes 1070-159	_	
1070-79	Rod & Shoe	F	
	Includes 1070-83 / Length is 8 3/8" (213mm)	62A
1070-79LR	Long Rod & Shoe		52.1
1070 02	Includes 1070-83 / Length is 12 3/8"		
1070-83	Arm Screw	F	
1070-159	Arm Screw	F	(B) 0077/2004
1070-201	Fifth Screw Spacer		3077/62A





LCN 1070 SERIES

Discontinued

Complete Arm Assemblies	
-------------------------	--

1070-3049 Hold-Open Arm F

Includes 1070-37, -41, -45, -49, -78H, -83, & -159

1070-3049/PA Hold-Open Arm w/PA I


Includes 1070-37, -41, -45, -49, -62PA, -78H, -83,


159, & -201


Individual Arm Parts

Illulviuuai Al III I al ts		
Individual arm parts for	r 1070-3049 & -3049/PA	
1070-37	Hold-Open Stud	F
1070-41	Hold-Open Nut	F
1070-45	HO Shoe	F
1070-49	HO Main Arm & Rod	F
	Includes 1070-83 & -159	
1070-62PA	Parallel Arm Shoe	F
	Includes 1070-201	
1070-78H	H Head & Tube	F
1070-83	Arm Screw	F
1070-159	Arm Screw	F
1070-201	Fifth Screw Spacer	
1070-3048	HO Head & Tube Assembly	F
	Includes 1070-37, -41, -45, & -78H	

Length is 6 3/4" (171mm)











1070-418


Discontinued

Mounting Plates		
1070-18	Mounting Plate	F
1070-18C	Mounting Plate	F
	Used to install a 1070 Series (1040 or 1050 Series Closer ho	
1070-18PA	Mounting Plate	F
Installation Acce	essories	
1070-61	Blade Stop Spacer	F
1070-65	Soffit Shoe	F

PA Shoe Adapter







Please specify finish **(F)**, size **(S)**, hand **(H)**, & voltage **(V)** where indicated. See the latest edition of the LCN Catalog for part descriptions and specifications on many of the items shown above. List prices for items shown above can be located in the current LCN Price List.



LCN CLOSERS 121 W. RAILROAD AVE. PO. BOX 100 PRINCETON, IL, USA 61356-0100

PHONE 800-526-2400 FAX 800-248-1460 www.lcnclosers.com ©2004 Ingersoll-Rand Company

Discontinued


Cylinder Assemblies_	
1371-3071	Cylinder Assembly F
	Includes screw pack (SRT standard – please specify other)
	Size '1' cylinder is adjustable from size 1-5 (Parallel Arm 1-4)
1371-3071DEL	Delay Cylinder Assembly F


Includes screw pack (SRT standard – please specify other) Size '1' cylinder is adjustable from size 1-5 (Parallel Arm 1-4)


Individual Cylinder Parts		
Individual cylinder pa	rts for 1371-3071	
1370-159	Arm Screw	F
1370-119	Cylinder Mounting Screw	
1370-3018	Mounting Bracket	
	Includes 1370-119	


Cover Caps	
1370-72	End Caps & Shaft Cover Set F
	Includes 1370-141 (1) -146 (1) & -334 (2)

Individual Cover Parts		
Individual cover	parts for 1370-72	
1370-141	Shaft Plug	F
1370-146	Shaft Cover	F
1370-334	End Cap	F












Discontinued

Complete Arm Assem	ıblies				
1370-3077	Regular Arm	F	3077 3077L		
	Includes 1370-77, -79, -83, & -159			(4)	
1370-3077L	Long Arm	F			
	Includes 1370-77, -79LR, -83, & -159)			
1370-3077/PA	Regular Arm w/PA	F			
	Includes 1370-62PA, -77, -79, -83, 15	19, & -201			
1370-3077/62A	Regular Arm w/62A	F			
	Includes 1370-62A, -77, -79, -83, & -	159	3077/PA		
					~
Individual Arm Parts					
_	or 1370-3077, -3077L, -3077/PA,				62PA - S
1370-62A	Auxiliary Parallel Arm Shoe	F			
1370-62PA	Parallel Arm Shoe	F S			201
	Includes 1370-201				
1370-77	Main Arm & Forearm	F			
	Includes 1370-159		0077/004	8	OOA
1370-79	Rod & Shoe	F	3077/62A	250	62A
	Includes 1370-83 / Length is 8 3/8" (213mm)			
1370-79LR	Long Rod & Shoe				Ů
	Includes 1370-83 / Length is 12 3/8"				
1370-83	Arm Screw	F			
1370-159	Arm Screw	F			
1370-201	Fifth Screw Spacer				





Discontinued

Complete Arm	Assemblies
1370-3049	Hold-Open Arm

Includes 1370-49, -83, -159, & -3048


1370-3049/PA Hold-Open Arm w/PA F


Includes 1370-49, -62PA, -83, -159, & -3048

F

Individual Arm Parts.

midividudi / Milli I di to-		
Individual arm parts for	1370-3049, -3049/PA, & -3049/	/62 <i>F</i>
1370-37	Hold-Open Stud	F
1370-41	Hold-Open Nut	F
1370-45	HO Shoe	F
1370-49	HO Main Arm & Rod	F
	Includes 1370-83 & -159	
1370-62A	Auxiliary Parallel Arm Shoe	F
1370-62PA	Parallel Arm Shoe	F
	Includes 1370-201	
1370-78H	H Head & Tube	F
1370-83	Arm Screw	F
1370-159	Arm Screw	F
1370-201	Fifth Screw Spacer	
1370-3048	HO Head & Tube Assy	F
	Includes 1370-37, -41, -45, & -78H	
	Length is 6 3/4" (171mm)	







Discontinued

Mounting Plates				
1370-18	Mounting Plate	F	•	
1370-18PA	Mounting Plate	F		
1370-18TJ	Mounting Plate	F	18	
	C		· · · · · ·	
Installation Accessori			_	
1370-61	Blade Stop Spacer	F		
1370-63	Drop Shoe Bracket	F		
1370-65	Soffit Shoe	F		
1370-418	PA Shoe Adapter	F		
			18PA	
			00	
				0
				••
				••
			18TJ	
				_
			0	••
				\searrow
				A
	^			0
	69//	_•		•
			<i>→</i>	D
	61	63	65	418

Please specify finish (F), size (S), hand (H), & voltage (V) where indicated. See the latest edition of the LCN Catalog for part descriptions and specifications on many of the items shown above. List prices for items shown above can be located in the current LCN Price List.



Cylinder Assemblies				450
1461-3071	Cylinder Assembly	F	H	159
1461-3071DEL	Includes screw pack (SRT standard – Size '1' cylinder is adjustable from si. Cylinder Assembly w/Delay			3018
1.01 50/1222	Includes screw pack (SRT standard – Size '1' cylinder is adjustable from si	please specify other	3071 3071DEL	
Individual Cylinder	Parts			
Individual cylinder pa	rts for 1461-3071, & -3071DEL			
1460-146	Shaft Cover	F		146
1460-159	Arm Screw	F		
1460-3018	Mounting Bracket		9	
				•
Covers				
1460-72	Slim Line Cover	F		
1460-72 1460-72DS1	Designer Series Metal Cover	F		
1100 /2001	Includes 1460-163G	1		72
1460-72EC	Smooth Slim Line Cover	F	163G	72 l
1460-72FC	Full Cover	F	^ ^	
	Includes 1460-163		\times	
1460-72LL	Lead Lined Cover	F		\bigcirc
	Includes 1460-163			
Individual Cover Par				
	for 1460-72DS1 & 1460-72FC			
1460-163	Arm Insert	F		72DS1
1460-163G	Arm Insert (DS1)	F		₩
				\ \ \ \ \
				72EC
				120
				163
				7250
				72FC




Complete Arm Asser	nblies			
1460-3077	Regular Arm	F		
	Includes 1460-77, -79, -83, & -159	_		
1460-3077/PA	Regular Arm w/PA	F		
1100 507 7/111	Includes 1460-62PA, -77, -79, -83, -1		_	
1460-3077/62A	Regular Arm w/62A Shoe	F	To the state of th	
1100 307770211	Includes 1460-62A, -77, -79, -83, &	-		
1460-3077L	Long Arm	F		
1100 3077 L	Includes 1460-77, -79LR, -83, & -15	=		
1460-3077HD	Heavy-Duty Regular Arm	F	3077	
	Includes 1460-77HD, -79, -83, & -15	59	3077L	
1460-3077HD/PA	Heavy-Duty Regular Arm w/P	PAF		(a)
	Includes 1460-62PA, -77HD, -79, -85			30
1460-3077HD/62A	Heavy-Duty Reg Arm w/62A			
	Includes 1460-62A, -77HD, -79, -83,			62PA
1460-3077HD/LG	Heavy-Duty Long Arm	F		
	Includes 1460-77HD, -79LR, -83, &	-159		201
			3077/PA	
Individual Arm Part				
_	for 1460-3077, -3077/PA, -3077/6	52A, -3077L,		90
	² A, -3077/62A, & -3077HD/LG			
1460-62A	Auxiliary Parallel Arm Shoe	F		62A
1460-62PA	Parallel Arm Shoe	F		•
1460.77	Includes 1460-201			
1460-77	Main Arm & Forearm	F	3077/62A	
1460 77110	Includes 1460-159	Г		
1460-77HD	Heavy Duty Main Arm & For	е Г		
1460.70	Includes 1460-159	Б		
1460-79	Rod & Shoe	F		
1460 701 D	Includes 1460-83 / Length is 8 3/8"			
1460-79LR	Long Rod & Shoe	F		
1460.02	Includes 1460-83 / Length is 12 3/8"		3077HD	
1460-83	Arm Screw	F 159 \	3077HD/LG	2
1460-159	Arm Screw	F		
1460-201	Fifth Screw Spacer	201		200
				62PA
^				201
	79LR	-77	3077HD/PA	
				♠
83				
	79		<i>[6]</i>	
83		77HD		62A 62A
•			2077HD/024	
			3077HD/62A	





Complete Arm Assemblies				
1460-3049	Hold-Open Arm	F		
	Includes 1460-49, -83H, -159, & -30-	48		
1460-3049/PA	Hold-Open Arm w/PA	F		
	Includes 1460-49, -62PA, -83H, -159,			
	-201, & -3048			
1460-3049L	Hold-Open Long Arm	F		
	Includes 1460-49, -83H, -159, & -30-	48L		


Indi	eubiv	Arm	Parts.
mui	viuua		I al to.

marriada Arm rans				
Individual arm parts for 1460-3049, -3049/PA, & -3049L				
1460-37	Hold-Open Stud	F		
1460-41	Hold-Open Nut	F		
1460-45	Hold-Open Shoe	F		
1460-49	HO Main Arm & Rod	F		
	Includes 1460-159			
1460-62PA	Parallel Arm Shoe	F		
	Includes 1460-201			
1460-78H	H Head & Tube	F		
	Includes 1460-83H			
1460-78HL	Head & Long Tube	F		
	Includes 1460-83H			
1460-83H	H Arm Screw	F		
1460-159	Arm Screw	F		
1460-201	Fifth Screw Spacer			
1460-3048	HO Head & Tube Assembly	F		
	Includes 1460-37, -41, -45, -78H, & -8	33H		
	Length is 5 3/4" (146mm)			
1460-3048L	HO Head & Long Tube Assy	F		
	Includes 1460-37, -41, -45, -78HL, &	-83H		
	Length is 8 5/8" (219mm)			









Please specify finish (F), size (S), hand (H), & voltage (V) where indicated. See the latest edition of the LCN Catalog for part descriptions and specifications on many of the items shown above. List prices for items shown above can be located in the current LCN Price List.

159



Complete Arm Assemblies_

1460-3077EDA Extra Duty Arm F

Includes 1460-159 & -201

1460-3077EDA/62G Extra Duty Arm w/62G F

Includes 1460-62G, -95, -159, -201, & -3035EDA

1460-3077EDA/145 Extra Duty Arm w/145 F


Includes 1460-95, -145, -159, & -3035EDA


Individual Arm Parts_


Individual arm parts for 1460-3077EDA, -3077EDA/62G, -3077/145

1460-62G	Thick Hub Shoe	F
	Includes 1460-201	
1460-95	Arm Stud	F
1460-145	Flush Transom Shoe	F
1460-159	Arm Screw	F
1460-201	Fifth Screw Spacer	
1460-3035EDA	EDA Main Arm & Forearm	F


Includes 1460-159











Please specify finish **(F)**, size **(S)**, hand **(H)**, & voltage **(V)** where indicated. See the latest edition of the LCN Catalog for part descriptions and specifications on many of the items shown above. List prices for items shown above can be located in the current LCN Price List.



LCN CLOSERS 121 W. RAILROAD AVE. PO. BOX 100 PRINCETON, IL, USA 61356-0100 PHONE 800-526-2400 FAX 800-248-1460 www.lcnclosers.com ©2004 Ingersoll-Rand Company

Complete Arm Ass	semblies
1460-3077CNS	Cush-n-St

Cush-n-Stop Arm

Includes 1460-124, -159, -201, & -384

F

1460-3049CNS Hold-Open Cush-n-Stop Arm F

Includes 1460-124, -159, -201, & -384

Individual Arm Parts_

Individual arm parts for	: 1460-3077CNS & -3049CNS	
1460-124	Plug	F
1460-159	Arm Screw	F
1460-201	Spacer	
1460-384	Stop	F

Complete Arm Assemblies_

1460-3077SCNS F Spring Cush-n-Stop Arm


Includes 1460-159, -201, & -3080


1460-3049SCNS HO Spring Cush-n-Stop Arm


Includes 1460-159, -201, & -3080


Individual Arm Parts_

Individual arm parts	for 1460-3077SCNS, & -	-3049SCNS
1460-159	Arm Screw	F
1460-201	Fifth Screw Spacer	
1460-3080	Spring Cush Block	F











Mounting Plates					_
1460-18	Mounting Plat	<u> </u>	F		
1460-18DS1	Mounting Plat		F		
1460-18FC	Mounting Plat		F		
1460-18PA	Mounting Plat		F		
1460-18PADS1	Mounting Plat		F		18
1460-18PAFC	Mounting Plat		F		
1400-101A1*C	Wiodinting 1 lat	C	1		
Installation Accesso	ries				
1460-30	Cush Shoe Su	nort	F	<u> </u>	
1460-61	Blade Stop Sp		F		
1460-65	Soffit Shoe	acci	F		4050
1460-418	Parallel Arm S	hoe Adapter	F		18FC
1460-419	Flush Panel A		F		
1400-417	Trushi Tanci Ti	aapter	1		•0
					(0
					18DS1
					18PA
				^	
		/°/)	0		
		(://	0		18PAFC
		Y	~	V	→
:	30	61		65	
		01		05	
	0		<u> </u>		. 0
	0		6		
()					
			le -	\geqslant	•
			* //		PADS1
	<i>4</i> 18			410	1,7,001

Please specify finish (F), size (S), hand (H), & voltage (V) where indicated. See the latest edition of the LCN Catalog for part descriptions and specifications on many of the items shown above. List prices for items shown above can be located in the current LCN Price List.

419



418

Cylinder Assemblies_

1460(1)T-3071 Cylinder Assembly F, S


> Includes screw pack (SRT is standard - please specify other) 1460T is adjustable size 2-4 / 1461T cylinder is adjustable

size 1-2

Individual Cylinder Parts_


1460T-159 Arm Screw F

1460T-3018 Mounting Bracket



Covers_


1460T-72	Slim Line Cover	F
1460T-72DS1	Designer Series Metal Cover	F
	Includes 1460T-163G	
1460T-72EC	Smooth Slim Line Cover	F
1460T-72LL	Lead Lined Cover	F
1460T-72FC	Full Cover	F
	Includes 1460T-163	



Individual Cover Parts_

Individual cover parts for 1460T-72, -72DS1, -72EC, -72FC, & -72LL

111011101111111111111111111111111111111	Parts 101 1 .001 /=, /=	221, /220, /21
1460T-146	Shaft Cover	F
1460T-163	Arm Insert	F
1460T-163G	Arm Insert (DS)) F





Complete Arm Assemblies_ 1460T-3077T Standard Arm F Includes 1460T-78, -82, -83H, -159 & -425 Individual Arm Parts_ Individual arm parts for 1460T-3077T 1460T-78 Main Arm & Tube F 3077T-Includes 1460T-159 1460T-82 Rod Includes 1460T-83H, & -425 1460T-83H F Arm Set Screw 1460T-159 Arm Screw F 1460T-425 Roller Locking Screw 1460T-3034 Track Roller Complete Track Assemblies_ Standard Track 1460T-3038 F Includes 1460T-73 (2), -141-2 (4), & 141-1 (4) 1460T-3038B Standard Track w/Bumper Includes 1460T-73 (2), -141-2 (4), -141-1 (4), & -169 1460T-3038H Standard Track w/Hold-Open F Includes 1460T-73 (2), -141-2 (4), -141-1 (4), & -3054 1460T-3038HB Standard Track w/Bump & HO F Includes 1460T-73 (2), -141-2 (4), -141-1 (4), -169 159 & -3054 73 Individual Track Parts_ Individual track parts for 1460T-3038, -3038B, 3038H, & -3038HB 1460T-73 End Cap 1460T-141-1 Track Plug F 3038 3038B F 1460T-141-2 Track Plug 3038H 1460T-169 **Bumper Assembly** 3038HB

Includes post & mounting screws

Hold-Open Spring Clip Includes cam & mounting screws

Track Roller


Please specify finish (F), size (S), hand (H), & voltage (V) where indicated. See the latest edition of the LCN Catalog for part descriptions and specifications on many of the items shown above. List prices for items shown above can be located in the current LCN Price List.



1460T-3034

1460T-3054

Mounting Plates			
1460T-18	Mounting Plate	F	
1460T-18DS1	Mounting Plate	F	
1460T-18FC	Mounting Plate	F	
1460T-18PA	Mounting Plate	F	
1460T-18PADS1	Mounting Plate	F	
1460T-18PAFC	Mounting Plate	F	





LCN1520 SERIES

Discontinued

Cylinder Assemblies.

1521-3071 Cylinder Assembly F

Includes screw pack (WMS standard – please specify other)

Size '1' cylinder is adjustable from size 1-4

Individual Cylinder Parts_

Individual cylinder parts for 1521-3071

1520-159 Arm Screw F


Covers_


1520-72MC F Metal Cover

Includes 1520-31 (2)

Individual Cover Parts_

Individual cover parts for 1520-72MC 1520-31 Cover Screw F







LCN1520 SERIES


Discontinued


1520-3077	Regular Arm	F	
	Includes 1520-77, -79, -83, & -1	59	
1520-3077/PA	Regular Arm w/62PA	F	
	Includes 1520-62PA, -77, -79, -83, 159, & -201		
1520-3077/62A	Regular Arm w/62A	F	
	Includes 1520-62A, -77, -79, -83	3, -159, & -201	

1520-3077L Long Arm Includes 1520-77, -79LR, -83, & -159

Individual Arm Parts.

Individual arm parts fo	r 1520-3077, -3077/PA, & -3077	7/62A
1520-62A	Auxiliary Parallel Arm Shoe	F
1520-62PA	Parallel Arm Shoe	F
	Includes 1520-201	
1520-77	Main Arm & Forearm	F
	Includes 1520-159	
1520-79	Rod & Shoe	F
	Includes 1520-83 / Length is 8 3/8" (2	213mm)
1520-79LR	Long Rod & Shoe	F
Includes 1520-83 / Length is 12 3		(314mm)
1520-83	Arm Screw	F
1520-159	Arm Screw	F
1520-201	Fifth Screw Spacer	







LCN1520 SERIES Discontinued

Comp	loto	A rm	Asseml	alies
V. (O1111)	IEIE	A	ASSEIII	11168

1520-3049 Hold-Open Arm F

Includes 1520-49, -83, -159, & -3048


1520-3049/PA Hold-Open Arm w/62PA


Includes 1520-49, 62PA, -83, 159, -201, & -3040

Individual Arm Parts.

Individual arm parts for	· 1520-3049 & -3049/PA,	
1520-37	Hold-Open Stud	F
1520-41	Hold-Open Nut	F
1520-45	HO Shoe	F
1520-49	HO Main Arm & Rod	F
	Includes 1520-83H & -159	
1520-62PA	Parallel Arm Shoe	F
	Includes 1520-201	
1520-78H	H Head & Tube	F
	Includes 1520-159	
1520-83	Arm Screw	F
1520-159	Arm Screw	F
1520-201	Fifth Screw Spacer	
1520-3048	HO Head & Tube Assy	F
	Includes 1520-37, -41, -78H, & -45	

Length is 6 3/4" (171mm)







LCN1520 SERIES

Discontinued

Complete Arm Assemblies_

1520-3077SCNS Spring Cush-n-Stop Arm F

Includes 1520 -159, -201, & -3080

1520-3049SCNS HO Spring Cush-n-Stop Arm F

Includes 1520-159, -201, & -3080


Individual Arm Parts_


Individual arm parts for 1520-3077SCNS, & -3049SCNS

1520-159 Arm Screw F

1520-201 Fifth Screw Spacer

1520-3080 Spring Cush Block F










LCN 1520 SERIES Discontinued

Mounting Plates					
1520-18PA	Mounting Plate	F			
1520-18TJ	Mounting Plate	F			
Installation Accessories					
1520-30	Cush Shoe Support	F			
1520-61	Blade Stop Spacer	F			









LCN 1520T SERIES

Discontinued

Cylinder Assemblies_

1521T-3071 Cylinder Assembly F

Includes screw pack (WMS standard – please specify other)

Size '1' cylinder is adjustable from size 1-3

Individual Cylinder Parts_

Individual cylinder parts for 1521T-3071


1520T-159 Arm Screw F


Covers_ F 1520T-72MC Metal Cover

Includes 1520T-31

Individual Cover Parts_

Individual cover parts for 1520T-72MC F 1520T-31 Cover Screw







LCN 1520T SERIES

Discontinued

Complete Arm Assemblies_

1520T-3077T Standard Arm F

> Includes 1520T-159 & roller (Roller not available separate)

Individual Arm Parts_

Individual arm parts for 1520T-3077T

1520T-159 Arm screw F

Complete Track Assemblies_

1520T-3038 Standard Track F

Includes 1520T-73 (2), -141-1 (4), & 141-2 (4)

1520T-3038H Standard Track w/Hold-Open F

Includes 1520T-73 (2), -141-1 (4), -141-2 (4), & -3054

Individual Track Parts_

Individual track parts for 1520T-3038, & -3038H

1520T-73 End Cap 1520T-141-1 Track Plug F 1520T-141-2 Track Plug

1520T-3054 Hold-Open Clip

Includes mounting screws

