

LockLink® Express

PC Requirements



Hardware: Intel Pentium II processor (Pentium III or IV recommended), CD-Rom, Mouse or compatible pointing device, VGA or Super VGA monitor.

Hard Disk Space: 80 MB for software plus whatever is required for stored data.

Memory: 128MB RAM Minimum or the memory required for the operating system whichever is greater.

Operating System: Microsoft Windows 98 SE (Second Edition), Microsoft Windows Me, Microsoft Windows NT 4.0 SP 6, Microsoft Windows 2000, Windows XP

Web Browser: In Order to view reports with the built-in viewer Internet Explorer 5.5 or higher must be installed. If the Operating system does not support IE5.5 then the reports will be viewed with the default browser. If no browser is installed then the reports cannot be viewed.

Required for programming with this software

- If offline locking system programming is done with an IR approved PDA device, the following is required:
 - available serial or USB port on the PC
 - approved PDA device with installed communications software and interface cables from Ingersoll Rand Security Technologies
- If offline locking system programming is done directly from the PC, the following is required:
 - available serial port on the PC or available PC card slot on the PC (PCMCIA card to serial adapter will be required and sold separately)
 - programming interface cables

Accessories



*IRPDA
Handheld
Programmer*



*CRM
Mag Card
Reader*



*CRP
Proximity
Reader*



*P101203
Interface
Module*



*P394548
Programming
Cable*

- Hand-held programming device
 - IRPDA when utilizing PC USB or serial port
- Cable and interface for programming offline products
 - P101203 Interface Module to PC or PDA
 - P394548 Programming Cable
- Enrollment Readers
 - CRP HID proximity enrollment reader
 - CRM Magnetic stripe card enrollment reader