





National Guard Products Inc.

1-800-
647-7874



148N/158 176/179V Astragal Seals



Installation Instructions

1. Cut astragal to length.
2. Place astragal as shown above, with gasketing slightly compressed.
3. Mark screw holes.
4. Drill pilot holes for screws using 7/64" bit.
5. Install with screws provided, working from one end to the other.
6. Adjust astragal so it does not impede closing and latching of doors.

4/07