


National Guard Products Inc.

1-800-647-7874



149M/189M Magnetic Astragal



Maximum distance between two pieces 5/16".
Install only on outside of out-swinging doors or inside of in-swinging doors

Installation Instructions

- 1.Cut astragal to length.
- 2.Position astragal as shown above.
3. Mark screw holes.
4. Drill pilot holes for screws using a 7/64" drill bit.
5. Install with screws provided, working from top down, adjusting for proper distance at each screw.
6. Adjust astragal so it does not impede proper closing and latching of doors.