

PARTS LIST

**687KIT* – Radio Frequency Option**

A Radio Frequency receiver (field installed) used to control the 6900 from a remote location. Wireless. Requires the 574, 576 or 577 (sold separately).

* Maximum codes: 12

Transmitters

- 9 volt battery
- Temperature: -4° F to 122° F
- Used with RF option and 687KIT

**572 - Key Fob**

- 1-1/2"w x 2-3/16"h x 9/16" d
- Two channel

**581**


- 2-3/8"w x 4-3/16"h x 15/16" d
- Single channel

**582**

- 2-3/8"w x 4-3/16"h x 15-16" d
- Two channel

Body Pump and Motor Assembly

Model Number	Hand	Part Number
6910, 6950	Left	6910LAP-L
6920, 6930, 6960, 6970		6920LAP-L
6910, 6950	Right	6910LAP-R
6920, 6930, 6960, 6970		6920LAP-R

**Miscellaneous Parts**

Model Number	Description
6700M	Cover
6700DAP	Drop angle bracket
6600-F1	Fuse (PC Board) 1.5 Amps
6600-F2	Fuse (120V Input) 3 Amps

Dummy Units

Model Number	Part Number
6910	6910DMY
6920	6920DMY
6930	6930DMY
6950	6950DMY
6960	6960DMY
6970	6970DMY

PARTS LIST

Arm and Track Assemblies



#6610-1 – Arm and Track Assembly
#7210-1A – Arm Assembly
#6610-1T – Track Assembly



#6620-1 – Arm Assembly
#6620-1W – Main Arm & Rod
#6620-12 – Adjusting Tube & Shoe



#6630-1 – Arm Assembly
#6630-1W – Main Arm & Rod
#6620-12 – Adjusting Tube & Shoe



Left hand shown

#6650-1L – Arm and Track Assembly (LH)
#6650-1R – Arm and Track Assembly (RH)
#7250-1L – Arm Assembly (LH)
#7250-1R – Arm Assembly (RH)
#6610-1T – Track Assembly



#6660-1 – Arm Assembly
#6660-11 – Rod & Snubber Assembly



#6670-1 – Arm Assembly
#6670-11 – Rod & Snubber Assembly