


777/888 Handing Chart

For Key-Retaining Function

Key-retaining: The key cannot be removed from the lock when the bolt is retracted and in the unlocked position.


Purpose: The key-retaining function is used so that cabinets are not left unlocked.

Handing: To install for any of the below handings, cycle the lock into the locked position before inserting the core.




vertical drawer (DWK)

Part-numbers:
888IC-DWK (Standard/Classic cores)
888P-DWK (Primus/Everest cores)



inverted drawer (DWK)

Part-numbers:
888IC-DWK (Standard/Classic cores)
888P-DWK (Primus/Everest cores)



OLYMPUS
LOCK
INC

206-362-3290 | 800-525-0954 | olympuslock.com