




CE-PTZ18x Accessories



CE-PTZ-CM/18x

Embedded Ceiling Mount


- Allows the CE-PTZ18x to be Recess Mounted
- Easy Installation
- Socket allows for easy Camera Install or Removal



CE-PTZ-IP/18x

Indoor Pendant Ceiling Mount


- Allows the CE-PTZ18x to be Pendant Mounted
- Easy Installation
- Aluminum Construction



CE-PTZ-WM/18x

Indoor Wall Mount


- Allows the CE-PTZ18x to be Wall Mounted
- Easy Installation
- Aluminum Construction



CE-PTZ-CR

Corner Mount

- Allows the CE-PTZ18x to be Corner Mounted (Requires CE-PTZ-WM/18x)
- Easy Installation
- Aluminum Construction



CE-PTZ-WP24

Cable Distribution Box

- Allows Easy Wiring Access for Power and Communication Cables
- Mounts Directly to CE-PTZ-IP/18x or CE-PTZ-WM/18x
- Aluminum Construction

N/A



CE-PTZ-WP24/COVER

Cover for CE-PTZ-WP24

- For use when CE-PTZ-WP24 is Remote Located and not used in conjunction with the CE-PTZ-IP/18x or CE-PTZ-WM/18x

N/A



CE-PTZ26x Accessories



CE-PTZ-IP

Outdoor Pendant Ceiling Mount

- Allows the CE-PTZ26x to be Pendant Mounted
- Easy Installation
- Aluminum Construction



CE-PTZ-WM

Outdoor Wall Mount

- Allows the CE-PTZ26x to be Wall Mounted
- Easy Installation
- Aluminum Construction



CE-PTZ-CR

Corner Mount

- Allows the CE-PTZ26x to be Corner Mounted (Requires CE-PTZ-WM)
- Easy Installation
- Aluminum Construction



CE-PTZ-PARAPET

Parapet Mount

- Allows the CE-PTZ26x to be Mounted over a Parapet
- Easy Installation
- Aluminum Construction



CE-PTZ-POLE

Pole Mount

- Allows the CE-PTZ26x to be Mounted to a Pole (Requires CE-PTZ-WM)
- Easy Installation
- Aluminum Construction



CE-PTZ-PA

1 1/2" Pipe Adapter

- Allows the CE-PTZ26x to be Mounted to 1 1/2" Pipe
- Aluminum Construction



CE-PTZ-WP24

Cable Distribution Box




- Allows Easy Wiring Access for Power and Communication Cables
- Mounts Directly to CE-PTZ-IP or CE-PTZ-WM
- Aluminum Construction



CE-PTZ-WP24/COVER

Cover for CE-PTZ-WP24

- For use when CE-PTZ-WP24 is Remote Located and not used in conjunction with the CE-PTZ-IP or CE-PTZ-WM



N/A

N/A

N/A

N/A

N/A