



Included Accessories

- · AC Adapter (cord length 72")
- Quick start guide and Safeguards

Warranty card

- L-type wrench (for securing screw of SD card slot)
- Software CD (User's manual, Quick installation guide, Installation Wizard)

Optional Accessories

Accessory Type	Part Number	Description	Photo
Outdoor Housing	JK-ACH13HBN	Outdoor housing with heater and blower. Comes with wall mount.	
Lens	YV21X28SR4A-SA2	Megapixel Lens 1/3", 2.8-6mm, F1.3, Day/Night	MP reco.
Lens	YV33X15SA-SA2	Megapixel Lens 1.31/3", 15-50mm, F1.5	MP reason
Lens	YV43X28SA-SA2	Megapixel Lens 1/3", 2.8-12mm, F1.4"	MP rest