VENT BLOWER KIT #1006168

This kit Contains:

- 1 1006168 Vent Blower Assembly
- 1 607014 Blower Gasket
- 2 68185 Flag Terminals
- 2 90515 Flag Terminal Insulators
- 1 1149930 Tube of RTV Sealant
- 1 608972 Instruction Sheet

Because of changes in components and manufacturing techniques, all of the enclosed parts may not be needed. During re-assembly, be sure to completely seal the joint between the "Vent Blower Assembly" and the "Vent Assembly" with the enclosed RTV sealant to prevent the leakage of flue products. After assembly, be sure to check the position of the blockage fitting as shown in Figure 1. It must be centered in the vent orifice and extended 3/16" above the orifice plate for proper operation.

FIGURE 1 3/16" Blockage Fitting Vent Assembly Pressure Fitting RTV Silicon Rubber Sealant If pressure fitting on Part #1149930 blower wheel housing is not used in the unit you are servicing, fill and seal it with RTV sealant. (3) Sheet Metal Screws Vent Blower Assembly Part #1006168

Revised 7/95 Part #608972