



Exploded View

Indoor Unit



Outdoor Unit

Model:AS-W126ERH0/BH0/VH0, AS-W096ERH0/BH0/VH0 (UL Chassis)



Replacement Parts List

Parts List (Indoor)

LOCATION No.	DESCRIPTION	PART No.			REMARKS
		AS-W126ERH0	AS-W126EBH0	AS-W126EVH0	
131410	CHASSIS ASSEMBLY	3141A20034C	3141A20034C	3141A20034C	
135311	GRILLE SSEMBLY,DISCHARGE(INDOOR)	3531A10373A	3531A10373A	3531A10373A	
135312	GRILLE ASSEMBLY,FRONT(INDOOR)	3531A10374D	3531A10374E	3531A10374F	
135516	COVER ASSEMBLY,MOTOR	3551A20156B	3551A20156B	3551A20156B	
146811	MOTOR ASSEMBLY,STEP	4681A20055A	4681A20055A	4681A20055A	
152302	FILTER(MECH),A/C	5230A20064A	5230A20064A	5230A20064A	
159901	VANE,HORIZONTAL	5990A20072A	5990A20072A	5990A20072A	
249951	CONTROL BOX ASSEMBLY,INDOOR	4995A20495U	4995A20495U	4995A20495U	
263230	THERMISTOR ASSEMBLY	6323A30002F	6323A30002F	6323A30002F	
264110	POWER CORD ASSEMBLY	6411A20013E	6411A20013E	6411A20013E	
266090	H.V ASSEMBLY	6609A10003Z	6609A10003Z	6609A10003Z	
267110	REMOTE CONTROLLER ASSEMBLY	6711A20083X	6711A20083X	6711A20083X	
268712	LCD MODULE	6306A90009A	6306A90009A	6306A90009A	
268714	PWB(PCB) ASSEMBLY,MAIN	6871A20914A	6871A20914A	6871A20914A	
342800	BEARING	4280A20004B	4280A20004B	4280A20004B	
346810	MOTOR ASSEMBLY,INDOOR	4681A20091J	4681A20091J	4681A20091J	
35211B	TUBE ASSEMBLY,TUBING	5211A29044A	5211A29044A	5211A29044A	
352150	HOSE ASSEMBLY,DRAIN	5251A20011G	5251A20011G	5251A20011G	
354210	EVAPORATOR ASSEMBLY,FIRST	5421A20258B	5421A20258B	5421A20258B	
359011	FAN ASSEMBLY,CROSS FLOW	5901A20017H	5901A20017H	5901A20017H	
733010	PLATE ASSEMBLY,INSTALL	3301A20020A	3301A20020A	3301A20020A	

NOTE) *Please ensure GCSC since these parts may be changed depending upon the buyer's request.
(GCSC WEBSITE <http://biz.LGservice.com>)

Parts List (Indoor)

LOCATION No.	DESCRIPTION	PART No.			REMARKS
		AS-W096ERH0	AS-W096EBH0	AS-W096EVH0	
131410	CHASSIS ASSEMBLY	3141A20034C	3141A20034C	3141A20034C	
135311	GRILLE SSEMBLY,DISCHARGE(INDOOR)	3531A10373A	3531A10373A	3531A10373A	
135312	GRILLE ASSEMBLY,FRONT(INDOOR)	3531A10374D	3531A10374E	3531A10374F	
135516	COVER ASSEMBLY,MOTOR	3551A20156B	3551A20156B	3551A20156B	
146811	MOTOR ASSEMBLY,STEP	4681A20055A	4681A20055A	4681A20055A	
152302	FILTER(MECH),A/C	5230A20064A	5230A20064A	5230A20064A	
159901	VANE,HORIZONTAL	5990A20072A	5990A20072A	5990A20072A	
249951	CONTROL BOX ASSEMBLY,INDOOR	4995A20495V	4995A20495V	4995A20495V	
263230	THERMISTOR ASSEMBLY	6323A30002F	6323A30002F	6323A30002F	
264110	POWER CORD ASSEMBLY	6411A20013E	6411A20013E	6411A20013E	
266090	H.V ASSEMBLY	6609A10003Z	6609A10003Z	6609A10003Z	
267110	REMOTE CONTROLLER ASSEMBLY	6711A20083X	6711A20083X	6711A20083X	
268712	LCD MODULE	6306A90009A	6306A90009A	6306A90009A	
268714	PWB(PCB) ASSEMBLY,MAIN	6871A20914B	6871A20914B	6871A20914B	
342800	BEARING	4280A20004B	4280A20004B	4280A20004B	
346810	MOTOR ASSEMBLY,INDOOR	4681A20091J	4681A20091J	4681A20091J	
35211B	TUBE ASSEMBLY,TUBING	5211A29044A	5211A29044A	5211A29044A	
352150	HOSE ASSEMBLY,DRAIN	5251A20011G	5251A20011G	5251A20011G	
354210	EVAPORATOR ASSEMBLY,FIRST	5421A20258B	5421A20258B	5421A20258B	
359011	FAN ASSEMBLY,CROSS FLOW	5901A20017H	5901A20017H	5901A20017H	
733010	PLATE ASSEMBLY,INSTALL	3301A20020A	3301A20020A	3301A20020A	

NOTE) *Please ensure GCSC since these parts may be changed depending upon the buyer's request.
(GCSC WEBSITE <http://biz.LGservice.com>)