

Replacement Cylinders for Honeywell® and Nortec® Steam Humidifiers



Aprilaire® Cylinder #	Manufacturer	OEM Cylinder Part #	Description/Capacity	OEM Humidifier Models
202AAC	Honeywell®	HM700ACYL2/U	5/10 lbs/hr; 110-277VAC 1ph	HM700A1000/U
202AAC	Nortec®	202	5/10 lbs/hr; 110-277VAC 1ph	NH-005, NH-010 and Resdelux
204AAC		204	5/10 lbs/hr; 440-600VAC 1ph	NH-010
303AAC		303	20 lbs/hr; 208-240VAC 3ph	NH-020/3Ph
309AAC		309	20 lbs/hr; 440-600VAC 1ph	NH-020/1Ph
311AAC		311	20 lbs/hr; 440-600VAC 3ph	NH-020/3Ph
321AAC		321	20 lbs/hr; 208-277VAC 1ph	NH-020/1Ph
411AAC		411	30 lbs/hr; 440-600VAC 3ph	NH-030
421AAC		421	30 lbs/hr; 208-240VAC 3ph	NH-030
605AAC		605	100/200 lbs/hr; 440-480VAC 3ph	NH-100
607AAC		607	50/75/150 lbs/hr; 460/575VAC 3ph, 100/200 lbs/hr; 575VAC	NH-150
621AAC		621	50/75/100/150/200 lbs/hr; 208-240VAC 3ph	NH-200

Instructions for installing new cylinder: Model NH-EL

1. Power OFF humidifier and install new cylinder. **Note:** Reconnect humidifier wires to the color-corresponding electrical connections on the new cylinder.
2. Cycle power ON, allow unit time for startup.
3. Select Menu from control panel, then enter code 0335.
4. Press Service NHEL.
5. Press Cylinder (A or B) RESET.
6. After warning, press <yes>.
7. Humidifier setup is complete; cylinder will fill with water when there is humidity demand.

Notes:

- A new drain o-ring is included with each replacement cylinder.
- Order additional AAC series replacement cylinders from your distributor.
- For all other inquiries, see original manufacturer's instructions.

Instructions for installing new cylinder: Models NHTC or NHPC

1. Power OFF humidifier and install new cylinder. **Note:** Reconnect humidifier wires to the color-corresponding electrical connections on the new cylinder.
2. Cycle power ON and allow unit time for startup.
3. Select Menu from control panel, then Enter code 0335.
4. Press Service Level, then <set>.
5. Press Reset Cylinder, then <set>.
6. After warning, press <yes>.
7. Humidifier setup is complete; cylinder will fill with water when there is humidity demand.

APRILAIRE®-branded replacement cylinders are manufactured by Aprilaire® for use as replacements for the corresponding HONEYWELL® and NORTEC® units as indicated. Aprilaire® products are not associated with HONEYWELL® or NORTEC®.



AprilairePartners.com
P.O. Box 1467 Madison, WI 53701-1467
800-334-6011 F: 608-257-4357

Printed in USA
©2016 Aprilaire – A division of Research Products Corporation
61001379 B2207074A 9.16