

AprilAire®

Ventilation

QUICK START GUIDE

Model V42SNX

Fresh Air Ventilator

⚠ WARNING

- **ATTENTION INSTALLER:** Read this manual before installing. Improper installation or maintenance may cause property damage or injury. It is recommended that installation, service, and maintenance be performed by a trained service technician. This product must be installed in compliance with all local, state, and federal codes.
- **ELECTRIC SHOCK HAZARD:** 120 volts may cause serious injury from electric shock. Disconnect electrical power to the HVAC system and ventilator before starting installation or servicing. Leave power disconnected until installation/service is completed.
- Inhalation of toxic gases or fumes can be harmful. The fresh air intake must be mounted in a location away from sources of dangerous toxic gases. Ducting system must be separate from other household exhaust systems.


⚠ CAUTION

- **SHARP EDGES MAY CAUSE INJURY FROM CUTS.** Use care when cutting and handling ductwork. Always wear glasses/goggles and gloves when installing the unit.
- Dropping may cause personal injury or equipment damage. Handle with care and follow installation instructions.

NOTICE


EQUIPMENT DAMAGE MAY OCCUR IF INSTALLATION INSTRUCTIONS ARE NOT FOLLOWED.

- Disconnect power to HVAC system during wiring to avoid electrical shorts.
- Screwing the brackets or any other hardware into any other location but the designated mount location may cause damage and invalidate the warranty.
- The fresh air duct from outside and to the house must be fully insulated to prevent condensation from forming on the ductwork.



CARTON CONTENTS

FIGURE 1: CARTON CONTENTS



- A. Quick Start Guide
- B. Innerpack
- C. Parts Bag with Mounting Bracket Screws
- D. Mounting Bracket
- E. Ventilator
- F. Innerpack

90-02857

For full
installation
instructions,
scan here:




READ AND SAVE THESE INSTRUCTIONS

MOUNT THE VENTILATOR

Reference the QR code on page 1 for detailed instructions.


1. Attach the mounting bracket to ventilator using the (4) provided screws. See **FIGURE 2**. Ensure screws are snug, do not over tighten.
NOTE: Using screws other than those provided may result in product damage.
2. Drive (1) screw, field provided, into the truss member or other appropriate surface where the ventilator will be mounted, leaving approximately 1/8" exposed. See **FIGURE 2**.
3. Hang the mounting bracket on the screw by the keyhole.
4. Drive (1) screw fully into each of the (2) remaining holes in the mounting bracket and tighten the keyhole screw.
5. Ensure the backdraft damper in the oval outlet collar is positioned correctly so that it will open when the ventilator is on, and will close on its own when the ventilator is off. If necessary, remove the damper, rotate it 180°, and reinstall on the other set of pivots. See **FIGURE 4**.

FIGURE 2: MOUNTING




90-02856

FIGURE 3: MOUNTING BRACKET ORIENTATIONS



90-02856

FIGURE 4: OUTLET COLLAR



90-02836

LIMITED WARRANTY

Terms of Coverage

Your AprilAire® Ventilator is expressly warranted to be free from defects in materials or workmanship for five (5) years from date of purchase.

What Is Covered

The exclusive obligation of AprilAire under this Limited Warranty shall be, at the sole discretion of AprilAire, to supply, without charge, a replacement for any component or product which is found to be defective. A defective part will be replaced pursuant to this Limited Warranty with a genuine AprilAire part. A defective product will be replaced pursuant to this Limited Warranty with a new AprilAire product of equal or similar features and functionality if the original product has been discontinued or is no longer available.

Not Covered by the Limited Warranty


- Consumable or maintenance products, such as, but not limited to: Air Filters, Evaporative Humidifier Water Panels, Steam Canisters, or Steam Humidifier Electrode Wires.
- Products purchased from third parties that were previously used, such as previously-used products purchased from eBay, similar third party/auction sites, or individuals selling used products.
- Labor charges, shipping costs, removal fees, service fees, or reinstallation costs.
- Materials furnished by the installer.
- Damage caused by misuse, abuse, improper installation, or failing to install, use, or maintain the product in accordance with the instructions provided.
- Damage to HVAC equipment caused by improper installation(s) or misapplication installation(s).
- Modifications, changes, repurposing, or alterations to the AprilAire product.
- Extended warranties or satisfaction guarantees offered by third parties.
- Cosmetic damage or normal wear and tear, including, but not limited to: scratches, peeling finish, or dents that do not impede the mechanical functionality of the product.
- Damage caused by acts of nature, including but not limited to: fire, collision, flood, wind, power surge, lighting strike, or mold.
- Damage caused during transit.
- Damage caused during installation due to failure to follow local, state, or federal laws, statutes, codes, or ordinances.
- Damage caused by defects in materials furnished by the installer.

Limit of Liability

IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE SHALL BE LIMITED IN DURATION TO THE FOREMENTIONED EXPRESS WARRANTY PERIOD. APRILAIRE LIABILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES, OTHER THAN DAMAGES FOR PERSONAL INJURIES, RESULTING FROM ANY BREACH OF THE FOREMENTIONED IMPLIED WARRANTIES OR THE ABOVE LIMITED WARRANTY IS EXPRESSLY EXCLUDED. THIS LIMITED WARRANTY IS VOID IF DEFECT(S) RESULT(S) FROM FAILURE TO INSTALL THE PRODUCT ACCORDING TO THE APRILAIRE INSTALLATION INSTRUCTIONS. IF THE LIMITED WARRANTY IS VOID DUE TO MISAPPLICATION OR IMPROPER INSTALLATION, ALL DISCLAIMERS OF IMPLIED WARRANTIES SHALL BE EFFECTIVE UPON INSTALLATION.

Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitation(s) may not apply to your situation. This Limited Warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Register Your AprilAire® Product



Thank you for choosing AprilAire. Register your product at aprilaire.com/warranty to receive important updates and notifications, and to streamline the process in the unlikely event you file a claim.

Your warranty registration information will not be sold or shared outside of this company.

Make a Warranty Claim

For questions regarding the Limited Warranty or to initiate a claim, contact AprilAire Customer Service at 1.800.334.6011 Monday through Friday, 7:00 a.m. to 5:00 p.m. Central Time.

At the sole discretion of AprilAire, you may be required to: return the product not later than thirty (30) days after the warranty period to the place of purchase or (if directed) to AprilAire, contact a professional contractor to provide warranty service, submit a product for testing related to a warranty claim, and/or send pictures of the original product with the serial number (if applicable) to AprilAire Technical Support for inspection as a condition to reviewing a claim and/or receiving a replacement product under this Limited Warranty.

AprilAire® is a registered trademark and division of Research Products Corporation, P.O. Box 1467, Madison, WI 53701-1467 USA.



Manufacturing
Use Only