

The diagram image is unavailable

Revision Number - 2

BLOWER PARTS

Callout	Name	Quantity	Description
	HOUSING-BLOWER Cat #: LB-28030AA Model/Part #: LB-28030AA	1	WELDED TO BLOWER DECK
19	PLATE-CUTOFF Cat #: 35A41 Model/Part #: LB-28357D	1	CUTOFF PLATE
20	RING-ORIFICE Cat #: 46A18 Model/Part #: LB-28040D	1	RING-ORIFICE
21	MOTOR-BLOWER Cat #: 32804 Model/Part #: P-8-10615	1	"1/3HP,1075RPM,208-230/60/1"
22	BAND-MOTOR Cat #: 32866 Model/Part #: P-8-9501	1	BAND-MOTOR MTG
23	ARM-MOTOR MTG Cat #: 37A34 Model/Part #: 37A3401	3	ARM-MOTOR MTG
24	CAPACITOR-BLR MTR Cat #: 53H32 Model/Part #: P-8-1947	1	"7MFD,370VAC"
25	WHEEL-BLOWER Cat #: 21708 Model/Part #: P-5-220	1	"1/2""BORE,10-5/8"" X 8""

CABINET PARTS

Callout	Name	Quantity	Description
	PANEL Cat #: LB-26792BA Model/Part #: LB-26792BA	1	LEFT SIDE
	BASE Cat #: 35C11 Model/Part #: LB-28002AA	1	BASE ASSY
	PIECE-FILLER Cat #: LB-28020C Model/Part #: LB-28020C	1	(FOR UNITS LESS ELEC HEAT)
	HINGE Cat #: LB-28153D Model/Part #: LB-28153D	2	HINGE
1	PANEL	1	RIGHT SIDE

Callout	Name	Quantity	Description
	Cat #: LB-26794BA Model/Part #: LB-26794BA		
2	PANEL Cat #: LB-26795AA Model/Part #: LB-26795AA	1	BLOWER ACCESS
3	PANEL Cat #: LB-26798AA Model/Part #: LB-26798AA	1	REAR ACCESS
4	COVER-CONTROL BOX Cat #: 14B89 Model/Part #: LB-28024CA	1	COVER-BOX
6	RACK-FILTER Cat #: 46A13 Model/Part #: LB-28013C	3	RACK-FLTR
7	COVER Cat #: LB-28021CA Model/Part #: LB-28021CA	1	ELEMENT
8	FILTER-AIR Cat #: 30348 Model/Part #: P-8-7821	1	"16"" X 24"" X 1"",WASHABLE"

CONTROL PANEL PARTS

Callout	Name	Quantity	Description
	FITTING Cat #: 59783 Model/Part #: P-8-4933	1	(FOR UNITS LESS ELEC HEAT)
	CLIP Cat #: P-8-5720 Model/Part #: P-8-5720	1	SECURING
	STRAIN RELIEF Cat #: P-8-8158 Model/Part #: P-8-8158	1	FITTING-STRAIN REL
	BLOCK-TERMINAL Cat #: 38674 Model/Part #: P-8-9957	1	(EXCLUDING 41-511 & 41-601)
15	TRANSFORMER Cat #: 59539 Model/Part #: P-8-5744	1	"230V PRI,24V SEC,30VA,NO FUSE"
17	RELAY Cat #: 45A76 Model/Part #: P-8-11318	1	"BLOWER- DPDT,24V(FOR UNITS WITH ELEC HEA
17	RELAY Cat #: 38276 Model/Part #: P-8-8479	1	"BLOWER- SPDT,24V(FOR UNITS LESS ELEC

Callout	Name	Quantity	Description
			HEA

COOLING PARTS

Callout	Name	Quantity	Description
	PAN-DRAIN Cat #: 46A11 Model/Part #: LB-26782BA	1	VERTICAL
	PAN-DRAIN Cat #: 46A12 Model/Part #: LB-26789BA	1	HORIZONTAL
10	COIL-INDOOR Cat #: 42A94 Model/Part #: LB-26776C	1	L/MANIFOLD
11	DISTRIBUTOR Cat #: 41A29 Model/Part #: P-8-10369	1	L/TUBES
13	ADAPTER Cat #: 68676 Model/Part #: P-8-2577	1	ADAPTOR

ELECTRIC HEATING PARTS

Callout	Name	Quantity	Description
	WIRE-ELEMENT Cat #: 82A41 Model/Part #: 37A4001	1	"2.5KW,240V(FOOTNOTE 7)"
	WIRE-ELEMENT Cat #: 82A53 Model/Part #: 37A4101	1	"5KW,240V"
26	ELEMENT-ELEC Cat #: LB-28052A Model/Part #: LB-28052A	1	CB11-41-601
26	ELEMENT-ELEC Cat #: 47A31 Model/Part #: LB-28053A	1	ELEMENT-ELEC
26	ELEMENT-ELEC Cat #: LB-28054A Model/Part #: LB-28054A	1	CB11-41-341
26	ELEMENT-ELEC Cat #: LB-28055A Model/Part #: LB-28055A	1	CB11-41-261

Callout	Name	Quantity	Description
26	ELEMENT-ELEC Cat #: LB-28056A Model/Part #: LB-28056A	1	CB11-41-171
27	CONTROL-LIMIT Cat #: 38A74 Model/Part #: 38A7401	1	"SPST,OUT 120,IN 95"
28	FUSE THERMAL Cat #: 87107 Model/Part #: P-8-10422	4	FUSE-THERMAL
29	RELAY Cat #: 35A2901 Model/Part #: 35A2901	1	"HEAT #2- DPST,24V(FOOTNOTE 6)"
29	RELAY-DELAY Cat #: 35A30 Model/Part #: 35A3001	1	"HEAT-SPST,24V"
29	RELAY Cat #: 35A3101 Model/Part #: 35A3101	1	"HEAT #1- DPST,24V(FOOTNOTE 5)"
30	RELAY Cat #: 35A2901 Model/Part #: 35A2901	1	"HEAT #2- DPST,24V(FOOTNOTE 6)"
30	RELAY-DELAY Cat #: 35A30 Model/Part #: 35A3001	1	"HEAT-SPST,24V"
31	BLOCK-TERMINAL Cat #: 66520 Model/Part #: P-8-163	1	STRIP-TERMINAL
32	BLOCK-FUSE Cat #: 37A32 Model/Part #: 37A3201	1	BASE-FUSE
32	BLOCK-FUSE Cat #: 37A33 Model/Part #: 37A3301	1	BASE-FUSE
33	FUSE Cat #: 57771 Model/Part #: P-8-418	2	"FRN TYPE,30AMP,250V"
33	FUSE Cat #: 37916 Model/Part #: P-8-5852	4	"FRN TYPE,60AMP,250V"

Note:

Note1: WHEN 35A3001 (ROBERTSHAW) IS N.A., ORDER LB-53619CA RELAY REPLACEMENT KIT. ONCE THE REPLACEMENT KIT HAS BEEN APPLIED, 58C9701 (THERMODISC) RELAY IS THE CORRECT REPAIR PART. Note2: WHEN 35A2901 (ROBERTSHAW) IS N.A., ORDER LB-53619CB RELAY REPLACEMENT KIT. ONCE THE REPLACEMENT KIT HAS BEEN APPLIED, 58C9901 (THERMODISC) RELAY IS THE CORRECT REPAIR PART. Note3: WHEN 35A3101 (ROBERTSHAW) IS N.A., ORDER LB-53619CC RELAY REPLACEMENT KIT. ONCE THE REPLACEMENT KIT HAS BEEN APPLIED, 69C9901 (THERMODISC) RELAY IS THE CORRECT REPAIR PART. Note4: WHEN 35A3001 (ROBERTSHAW) IS N.A., ORDER LB-53619CC RELAY REPLACEMENT KIT. ONCE THE REPLACEMENT KIT HAS BEEN APPLIED, 69C9901 (THERMODISC) RELAY IS THE CORRECT REPAIR PART. Note5: WHEN 35A3101 (ROBERTSHAW) IS N.A., ORDER LB-53619CD RELAY REPLACEMENT KIT. ONCE THE REPLACEMENT KIT HAS BEEN APPLIED, 69C9801 (THERMODISC) RELAY IS THE CORRECT REPAIR PART. Note6: WHEN 35A2901 (ROBERTSHAW) IS N.A., ORDER LB-53619CD RELAY REPLACEMENT KIT. ONCE THE REPLACEMENT KIT HAS BEEN APPLIED, 69C9801 (THERMODISC) RELAY IS THE CORRECT REPAIR PART. Note7: THIS PART MUST BE PLACED LAST IN SEQUENCE, FARTHEST DOWNSTREAM FROM BLOWER.