

GUH96T-GUH/GDD96C "ECM" GAS FURNACES M SERIES CRITICAL PARTS LIST

DESCRIPTION	PART NUMBER	USED ON THESE MODELS
102712-01 Wheel-Blower 10 X 9 X 1/2	69W52	GUH96T045B3M, GUH96T070B3M, GUH96T090C3M
102703-02 Wheel-Blower 11 X 11 X 1/2	69W50	GUH96T090C5M, GUH96T110C5M, GUH96T135D5M
LB-29333BCG WHEEL- BLOWER	89J10	GUH96C(045,070)B3M, GDD96C045B3M
LB-29333BM WHEEL-BLOWER	16596	GUH96C090C4M, GDD96C090C4M
LB-29333BCW WHEEL-BLOWER	36M22	GUH96C110C5M, GDD96C070B4M
102809-02 Hose Drain UH	71W36	GUH96T(ALL)M, GUH96C(ALL)M
102809-03 Hose Drain	98W72	GUH96T(ALL)M, GUH96C(ALL)M
102865-01 Hose Drain (DF)	71W46	GDD96C045B3M, GDD96C070B4M
102865-02 Hose Drain (DF)	71W47	GDD96C090C4M
610587-03 Module Kit	10B70	GUH96T045B3M
610587-05 Module Kit	10B72	GUH96T070B3M
610587-06 Module Kit	10B73	GUH96T090C3M
610587-17 Module Kit	10B84	GUH96T090C5M
610587-18 Module Kit	10B85	GUH96T110C5M
610587-19 Module Kit	10B92	GUH96T135D5M
ARM-MOTOR MTG (4)	49L97	GUH96T(090,110)C5M, GUH96T135D5M
610588-01 Motor Kit	10B66	GUH96T045B3M, GUH96T070B3M, GUH96T090C3M
610588-02 motor kit	10B67	GUH96T(090,110)C5M, GUH96T135D5M
607421-02 X13 1/2HP Motor - Programmed	81W33	GUH96C(045,070)B3M, GDD96C045B3M
607421-06 X13 3/4HP Motor - Programmed	81W37	GUH96C090C4M, GDD96C090C4M
607421-11 X13 1HP Motor - Programmed	81W42	GUH96C110C5M
607421-04 X13 3/4HP Motor - Programmed	81W35	GDD96C070B4M
MOUNT-MOTOR	18M68	GUH96T045B3M, GUH96T070B3M, GUH96T090C3M, GUH96C(045,070)B3M, GUH96C090C4M, GDD96C045B3M, GDD96C090C4M
MOUNT-MOTOR	32M17	GUH96T(090,110)C5M, GUH96T135D5M, GUH96C110C5M, GDD96C070B4M
102907-01 Roll Out Switch (210F)	71W49	GUH96T(ALL)M, GUH96C(ALL)M, GDD96C(ALL)M
103181-02 VALVE-GAS (2 STG NAT)	83W12	GUH96T(ALL)M
100365-01 VALVE-GAS (Single Stage)	73W17	GUH96C(ALL)M, GDD96C(ALL)M
607308-14 KIT-IGNITION CONTROL	14Y53	GUH96T(ALL)M

607436-03 Ignition Control Kit	16C81	GUH96C(ALL)M, GDD96C(ALL)M
102317-01 SWITCH-INTERLOCK	51W15	GUH96T(ALL)M, GUH96C(ALL)M, GDD96C(ALL)M
602866-04 Burner Assy (045)	69W87	GUH96T045B3M, GUH96C045B3M, GDD96C045B3M
ASSY BURNER (6)	69W88	GUH96T070B3M, GUH96C070B3M, GDD96C070B4M
ASSY BURNER (8)	69W89	GUH96T090C3M, GUH96T090C5M, GUH96C090C4M, GDD96C090C4M
ASSY BURNER (10)	69W90	GUH96T110C5M, GUH96C110C5M
ASSY BURNER (12)	69W91	GUH96T135D5M
LB-94726T HOUSING-BLOWER	70W40	GUH96T045B3M, GUH96T070B3M, GUH96T090C3M
LB-94726X HOUSING-BLOWER	70W42	GUH96T(090,110)C5M, GUH96T135D5M
LB-94726J HOUSING-BLOWER	57M87	GUH96C(045,070)B3M, GDD96C045B3M
LB-94726K HOUSING-BLOWER	57M88	GUH96C090C4M, GDD96C090C4M
LB-94726L HOUSING-BLOWER	57M89	GUH96C110C5M, GDD96C070B4M
LB-74940B Flame Sensor Kit	69W43	GUH96T(ALL)M, GUH96C(ALL)M, GDD96C(ALL)M
104549-11 Pressure Switch 2-STG-.70/- .40	14A53	GUH96T045B3M
104549-06 Pressure Switch 2-STG-.85/- .50	14A48	GUH96T070B3M, GUH96T090C3M, GUH96T090C5M
104549-03 Pressure Switch 2-STG-.90/- .50	14A45	GUH96T110C5M
104549-01 Pressure Switch 2-STG-.90/- .45	14A43	GUH96T135D5M
104371-01 SWITCH - PRESSURE .65	11U64	GUH96C045B3M, GDD96C045B3M
104371-09 Pressure Switch Kit 0.90"	10U94	GUH96C070B3M, GUH96C090C4M, GUH96C110C5M, GDD96C070B4M, GDD96C090C4M
42J3201 TRANSFORMER	42J32	GUH96T(ALL)M, GUH96C(ALL)M, GDD96C(ALL)M
LB-112237B IGNITER	70W16	GUH96T(ALL)M, GUH96C(ALL)M, GDD96C(ALL)M
102857-08 Control-Limit (165F)	75W15	GUH96T070B3M, GUH96C070B3M
102857-07 Control-Limit (175F)	73W20	GUH96T045B3M, GUH96T090C3M, GUH96C045B3M, GDD96C045B3M
102857-05 Control-Limit (150F)	73W18	GUH96T(090,110)C5M, GDD96C070B4M
102857-04 Control-Limit (145F)	71W44	GUH96T135D5M, GUH96C110C5M
102857-06 Control-Limit (155F)	73W19	GUH96C090C4M
102857-03 Control-Limit (140F)	71W43	GDD96C090C4M
605099-07 DRAIN TRAP (GOODY BAG)	95W17	GUH96T(ALL)M, GUH96C(ALL)M, GDD96C(ALL)M