



THE MARK (→) SHOWS PIPING DIRECTION




※NOTE:
INCLUDING MOUNTING PLATE


REQUIRED SPACE



WIRELESS REMOTE CONTROLLER (ARC480A83)



BLADE ANGLE



STANDARD LOCATIONS OF WALL HOLES

