

Parts List Number :000092140

Model Number :L8X1B070U4XSAAA

Part No.	Reference No.	Quantity	Description
0000092142~S	*		BLOWER
0000092144~S	*		BURNER & INDUCER
0000092141~S	*		GENERAL ASSEMBLY
0000092143~S	*		HEAT EXCHANGER
0000092208~S	*		MODEL NUMBER DESCRIPTION

Part No.	Reference No.	Quantity	Description
000006023~P	*		BLOWER PARTS LIST

Part No.	Reference No.	Quantity	Description
CNT08115	*	2	CONTROL; BLOWER LIMIT
HUS04416	*	1	HOUSING; BLOWER HOUSING & WHEEL
MNT02481	*	1	MOUNT; MOTOR MOUNT KIT, INCLUDES BAND, ARMS AND HARDWARE
MOT19515	*	1	MOTOR; BLOWER MOTOR
WHL03842	*	1	WHEEL; BLOWER WHEEL

Part No.	Reference No.	Quantity	Description
000006007~P	*		BURNER & INDUCER PARTS LIST

Part No.	Reference No.	Quantity	Description
GKT05042	*	1	GASKET; INDUCER GASKET
GKT05043	*	2	GASKET; GAS/AIR VENTURI GASKET ONLY (QTY: 2)
GKT05055	*	1	GASKET; IGNITOR/FLAME SENSOR GASKET ONLY (NOT SHOWN, QTY: 20)
HED01275	*	1	HEAD; PRE-MIX BURNER HEAD ASSEMBLY
MOT19517	*	1	MOTOR; INDUCER MOTOR (W/GASKET)
ORF02094	*	1	ORIFICE; GAS ORIFICE (NATURAL GAS)
PLT06743	*	1	PLATE; COMBUSTION AIR ORIFICE
SEN02909	*	1	SENSOR; IGNITOR & FLAME SENSOR ASSEMBLY
SWT04445	*	1	SWITCH; ROLL-OUT LIMIT SWITCH
TUB15341	*	1	TUBE; FLEXIBLE GAS LINE, STAINLESS STEEL
TUB15342	*	1	TUBE; GAS/AIR VENTURI MIXING TUBE
VAL19593	*	1	VALVE; GAS VALVE

Part No.	Reference No.	Quantity	Description
000006021~P	*		GENERAL ASSEMBLY PARTS LIST

Part No.	Reference No.	Quantity	Description
CNT08116	*	1	BOARD; CONTROL BOARD
DOR04587	*	1	DOOR; DOOR SET
FUS02593	*	1	FUSE; FUSE
HSE02029	*	1	HOSE; HIGH TEMP HOSE
PNL37006	*	1	PANEL; TOP PANEL
WIR10000	*	1	WIRE; SET OF WIRES

Part No.	Reference No.	Quantity	Description
000006004~P	*		HEAT EXCHANGER PARTS LIST

Part No.	Reference No.	Quantity	Description
EXC02956	*	1	EXCHANGER; HEAT EXCHANGER
PAN04277	*	1	PAN; COLLECTOR PAN (W GASKET)
SWT04436	*	1	SWITCH; DOOR SWITCH
SWT04438	*	1	SWITCH; PRESSURE SWITCH
SWT04442	*	1	SWITCH; MAIN AIR LIMIT SWITCH
TRR03028	*	1	TRANSFORMER; TRANSFORMER

Part No.	Reference No.	Quantity	Description
000006041~P	*		MODEL NUMBER GRAPHIC

MODEL NUMBER DESCRIPTION

75011116

RB
B

S-SERIES FURNACE

Example Model Number:

S 9 V 2 B 0 8 0 U 3 P S A A A
1 - - - - 5 - - - - 10 - - - - 15

Digit 1 – Level

S = Series
L = 14 ng/J Ultra-Low NOx

Digit 2 – AFUE

8 = 80%
9 = 90% or higher

Digit 3 – Blower Type

B = Builder Series (May be PSC or CTM)
P = PSC
X = CTM
V = Variable Speed

Digit 4 – Gas Valve Stages

1 = SingleStage
2 = 2 Stage
M = Modulating

Digit 5 – Cabinet Width

A = 14.5 wide
B = 17.5 wide
C = 21.0 wide
D = 24.5 wide

Digits 6,7,8 – BTU input

080 = 80,000 BTUH

Digit 9 – Poise Options

U = 3 way
D = Dedicated Downflow
M = 4 Way Poise

Digit 10 – Airflow Capacity for Cooling

2 = 2 Tons
3 = 3 Tons
4 = 4 Tons
5 = 5 Tons

Digit 11 – Inducer Type

P = PSC
X = CTM
V = Variable Speed

Digit 12 – Communicating capability

S = 24 Volt
C = Communicating System Control
T = 24 Volt, 40ng/J NOx
D = Communicating System Control,
40ng/J NOx

Digit 13 – Major Design Change

Digit 14 – Minor Design Change

Digit 15 – Service Digit Change

