


Part No.	Reference No.	Quantity	Description
0000100081~S	*		CONTROLS & WIRES
0000100080~S	*		GENERAL ASSEMBLY
0000100082~S	*		MODEL NUMBER DESCRIPTION

Part No.	Reference No.	Quantity	Description
0000009173~P	*		CONTROLS & WIRES PARTS LIST

CONTROLS & WIRES
INDOOR LOW AMBIENT HIGH WALL
1.5 TON

75012296

REV.
A



All orderable Service Parts are identified for this product.

Parts that are not identified, will not be available to order.

This is a typical illustration. The unit in the field may not appear exactly as shown.


Part No.	Reference No.	Quantity	Description
BOX03415	1	1	BOX; ELECTRIC ASSEMBLY
BRD06401	2	1	BOARD; MAIN BOARD
CAP01324	3	1	CAP; JUMPER
BOX02965	4	1	BOX; ELECTRIC
CNT07852	8	1	CONTROL; REMOTE INCLUDES HOLDER
BOX02964	10	1	BOX; LOWER SHIELD
BRD02648	11	1	BOARD; TERMINAL,
COV05102	12	1	COVER; ELECTRIC BOX (PLASTIC)
COV05434	13	1	COVER; ELECTRIC BOX (METAL)
SEN02447	14	1	SENSOR; TEMPERATURE

Part No.	Reference No.	Quantity	Description
0000009169~P	*		GENERAL ASSEMBLY PARTS LIST

GENERAL ASSEMBLY
INDOOR LOW AMBIENT HIGH WALL
1.5 TON

75012295

REV.
A



All orderable Service Parts are identified for this product.

Parts that are not identified, will not be available to order.

This is a typical illustration. The unit in the field may not appear exactly as shown.

Part No.	Reference No.	Quantity	Description
PNL34618	2	1	PANEL; FRONT
BRD05637	3	1	BOARD; DISPLAY
FLR08705	4	2	FILTER; SUB-ASSY
COV05103	5	1	COVER; TERMINAL
BRD05535	6	1	BOARD; DECORATIVE (LEFT AND RIGHT SIDES)
PNL33743	7	1	PANEL; FRONT CASE ASSEMBLY
LVR01189	8	1	LOUVER; GUIDE 33 X 4 X 1
BUS02047	9	2	BUSHING; AXILE
LVR01198	10	3	LOUVER; AIR (MANUAL)
BRK04747	11	1	BRACKET; AIR OUTLET
BUS02159	12	1	BUSHING; LEFT AXILE
CAS02085	13	1	CASE; REAR ASSEMBLY
PLU01245	14	1	PLUG; DRAIN PAN
FAN05604	15	1	FAN; CROSS FLOW
GKT04728	16	1	GASKET; O RING, BEARING
BRG01961	17	1	BEARING; RING
SUP06144	18	1	SUPPORT; COIL
PLT05903	19	1	PLATE; MOTOR MOUNTING (METAL)
MOT17359	20	1	MOTOR; FAN
PLT05904	21	1	PLATE; MOTOR MOUNTING (PLASTIC)
COV05105	22	1	COVER; REFRIGERANT PIPE
HSE01636	23	1	HOSE; DRAINAGE HOSE
LVR01187	24	1	LOUVER; SIDE GUIDE
MOT17358	25	1	MOTOR; STEPPER
COV05146	27	3	COVER; SCREW
COL28284	28	1	COIL; EVAPORATOR ASSY

Part No.	Reference No.	Quantity	Description
0000009276~P	*		MODEL NUMBER GRAPHIC

NOMENCLATURE
INDOOR LOW AMBIENT HIGH WALL

75012307

REV.
A

Model Number Example

M 4 M L W 1 8 0 9 A 1 N 1 A A
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15

Digit 1 = Brand Name
M = Ameristar

Digit 2 = Refrigerant
2 = R22
4 = R410A

Digit 3 = Indoor/Outdoor
M = Indoor

Digit 4 = Unit Type
HP = Heat Pump
L = Low Ambient

Digit 5 = System Type
W = High Wall

Digit 6-7 = Efficiency Tier (SEER)

18 - 18 SEER

Digit 8-9 = Nominal Capacity

09 = .75 ton

12 = 1.0 ton

18 = 1.5 ton

24 = 2.0 ton

Digit 10 = Major Development Sequence
Alphabet Letter; "A" through "Z"

Digit 11 = Electric Power Supply Characteristics
1 = 200-230V/1PH/60Hz or 208-230V/1PH/60Hz

Digit 12 = Region of Sale
N = North American Market

Digit 13,14,15 = Minor Design Sequence - Design Change
Alphabet Letter; "A" through "Z"

All orderable Service Parts are identified for this product.

Parts that are not identified, will not be available to order.

This is a typical illustration. The unit in the field may not appear exactly as shown.

