



**Fig. 3: Prestige Jacket Components**

| Item | Part No. | Description                         |
|------|----------|-------------------------------------|
| 1    | PSCS01   | Display/Control Panel               |
| 2    | PSCS02   | Display Back Panel                  |
| 3    | PSJKT01B | Connection Flange Panel             |
| 4    | PSJKT02B | Base Panel                          |
| 5    | PSJKT01F | Front Jacket Panel                  |
| 6    | PSJKT01R | Rear Jacket Panel                   |
| 7    | PSJKT01S | Side Jacket Panel (Left and Right)  |
| 8    | PSJKT01T | Top Jacket Panel - Front            |
| 9    | PSJKT02T | Top Jacket Panel - Rear             |
| 10   | PSJKT03  | Control Cover Panel                 |
| 11   | PSRKT21  | Wall Mounting Bracket with Hardware |