



REPAIR PARTS

AH SERIES Commercial Air Handlers

AH120-00
AH90-00

This manual is to be used by qualified technicians only.

© 1994-2008 Goodman Manufacturing Company, L.P. ♦ 5151 San Felipe, Suite 500 ♦ Houston, TX 77056

Important Information

Index

Functional Parts List	3
Illustration and Parts	4 - 7

Views shown are for parts illustrations only, not servicing procedures.

Text Codes:

AR - As Required

NA - Not Available

NS - Not Shown

00000000 - See Note

QTY - Quantity Example (QTY 3) (If Quantity not shown, Quantity = 1)

M - Model Example (M1) (If M Code not shown, then part is used on all Models)

Expanded Model Nomenclature:

Example M1 - Model#1 M2 - Model#2 M3 - Model#3

Goodman Manufacturing Company, L.P. is not responsible for personal injury or property damage resulting from improper service. Review all service information before beginning repairs.

Warranty service must be performed by an authorized technician, using authorized factory parts. If service is required after the warranty expires, Goodman Manufacturing Company, L.P. also recommends contacting an authorized technician and using authorized factory parts.

Goodman Manufacturing Company, L.P. reserves the right to discontinue, or change at any time, specifications or designs without notice or without incurring obligations.

For assistance within the U.S.A. contact:
Consumer Affairs Department
Goodman Manufacturing Company, L.P.
7401 Security Way
Houston, Texas 77040
877-254-4729-Telephone
713-863-2382-Facsimile

For assistance outside the U.S.A. contact:
International Division
Goodman Manufacturing Company, L.P.
7401 Security Way
Houston, Texas 77040
713-861-2500-Telephone
713-863-2382-Facsimile

Functional Parts

Part

No: **Description:**

B13400405S	BLOWER MOTOR 1-1/2 HP
B1370734	BLOWER RELAY
B1370731	CONTACTOR RELAY
B1141654	TRANSFORMER 208/240, 75VA, RESETTABLE


SPECIAL PARTS

IO-115	INSTALLATION INSTRUCTIONS
RP-182A	REPAIR PARTS MANUAL

Expanded Model Nomenclature

M1 - AH120-00
M2 - AH90-00

Replacement Parts List



Replacement Parts List

Ref. Part No:	No:	Description:	Ref. Part No:	No:	Description:
<i>Image 1:</i>					
11	2121101	LEFT SIDE PANEL			
21	2121102	RIGHT SIDE PANEL			
31	2162500	SIDE PANEL (M2)			
31	2162501	SIDE PANEL (M1)			
41	2122004	ACCESS CORNER (QTY 4)			
51	2122003	FRONT CORNER PANEL			
61	2122002	REAR CORNER PANEL			
71	2122001	FRONT CENTER PANEL			
81	2122000	REAR CENTER PANEL			
91	2179501	BLOWER SCROLL BRACE (M2)			
91	2179509	BLOWER SCROLL BRACE (M1)			
101	2179507F	MOTOR MOUNT PLATE (M2)			
101	2179508	MOTOR MOUNT PLATE [OBSOLETE] (M1)			
111	2179500F	MOTOR SHIELD			
121	2133602PDG	DRAIN PAN ASSY			
131	B13400405S	BLOWER MOTOR 1-1/2 HP			
141	B2120001	VARIABLE PITCH SHEAVE 1VL44 X 3/8" (M1)			
141	B2120000	VARIABLE PITCH SHEAVE 3.15" (M2)			
151	B2120010	FIXED SHEAVE (M2)			
151	B2120011	FIXED SHEAVE (M1)			
161	B2110006	FAN BELT, NOTCHED (M1)			
161	B2110005	NOTCHED FAN BELT (M2)			
171	B2182100	BLOWER HOUSING AND WHEEL (12 X 12) (M2)			
171	B2182101	BLOWER HOUSING AND WHEEL (12 X 15) (M1)			
181	2156500S	TUBING ASSY, EVAP COIL (M1)			
181	2156501S	TUBING ASSY, EVAP COIL (M2)			
191	B1141654	TRANSFORMER 208/240, 75VA, RESETTABLE			
201	B1370731	CONTACTOR RELAY			
211	B1370734	BLOWER RELAY			
221	B1369607	AIR FILTER			
231	B2170100	TOP FILTER ROD (QTY 3)			
241	B1392301	PLASTIC CLAMP (QTY 3)			
251	B2170101	BOTTOM FILTER ROD (QTY 3)			
261	B1284656	TXV VALVE (M2)			
271	B1284654	TXV VALVE (M1)			
NS	B2213800	FLOWRATOR, 8 TUBE, NO PISTON (M1)			
NS	B1398600	KEY 1/4" X 1.25" LG (M1)			
NS	B1398601	KEY 3/4" X 1.25" LG (M2)			

Expanded Model Nomenclature

M1 - AH120-00
M2 - AH90-00

